=	ŀ	
L	ı	
9	,	
	1	
7	_	
-		
C	J	
۵	ľ	
Ļ	1	
=	2	
_	I	
_		



STUDENT NAME_

MANDATORYFIREFIGHTER SKILLS EVALUATION FORM

STUDENT NAME (Last, First MI)				
DRIVERS LICENSE #	FF CERTIFICATION # (If any	ON # (If an)		
FIRE DEPARTMENT/AGENCY		COUNTY	 	
TEST LOCATION	IDHS COURSE #	JRSE #		
Skill		DATE	PASS	EVALUATOR SIGNATURE

	ONIII	DAIE	LASS	EVALUATOR SIGNATURE
2 1	DON AND DOFF ARTICLES OF PROTECTIVE CLOTHING/EQUIPMENT			
3 1	DONNING SCBA FACE MASK (ATTACHED FACEPICE MOUNTED REGULATOR)			
3 1a	DONNING SCBA FACE MASK (UNATTACHED FACEPIECE MOUNTED REGULATOR)			
3 2	DON SCBA BACKPACK USING CROSSED ARMS OR REGULAR COAT METHOD			
3 3	3A E			
3 4	CLEAN AND INSPECT AN SCBA UNIT (AFTER USE)			
4 1	CONDUCTING A PRIMARY SEARCH			
4 2	RESTRICTED OPENING REMOVAL			
4 3	DEMONSTRATE TECHNIQUES FOR ACTION WHEN TRAPPED OR DISORIENTED			
4a 1	USE HYDRAULIC SPREADER			
4a 2	USE HYDRAULIC SHEARS			
4a 3	BUILDING A BOX CRIB			
5 1	USE THE TWO FIREFIGHTER METHOD TO COULE HOSE			
5 2	DEMONSTRATE A BASIC STRAIGHT HOSE ROLL			
53	DEMONSTRATE A TWO PERSON DONUT HOSE ROLL			
5 4	PERFORM A STREET DRAG			
2 2	INSPECT CLEAN AND DRY HOSE			
2 6	INSPECT HOSE COUPLINGS AND REPLACE A HOSE GASKET			
2 2	ACCORDION LOAD AND UNLOAD HOSE			
2 8	FLAT LOAD AND UNLOAD HOSE			
2 9	PERFORM A SHOULDER LOOP HOSE CARRY			
6 1	OPERATE A FOG STREAM NOZZLE			
6 2	OPERATE A SOLID STREAM NOZZLE			
6 3	MAKE SOFT SLEEVE HYDRANT CONNECTION			
6 4	PERFORM A SINGLE SECTION DRAIN AND CARRY			
6 5	ADVANCE A LINE INTO A STRUCTURE			
9 9	ADVANCE A LINE DOWN AN INTERIOR STAIRWAY			
2 9	HANDLE A MEDIUM SIZED CHARGED HOSELINE (ONE FIREFIGHTER)			
8 9	HANDLE A MEDIUM SIZED CHARGED HOSELINE (TWO FIREFIGHTERS)			

STUDENT NAME

DRIVER S LICENSE #

	Skill	DATE	PASS	EVALUATOR SIGNATURE
69	HANDLE A LARGE SIZED CHARGED HOSELINE (TWO FIREFIGHTERS)			
6 10	USE COMBINATION ATTACK TO CONTROL AND/OR SIMULATE EXTINGUISHMENT OF A CLASS A FIRE WITHIN A STRUCTURE			
7 1	DEMONSTRATE THE LOW SHOULDER ROOF LADDER LIFE AND CARRY (FROM VERTICAL FOR FLAT RACKING)			
7 2	DEMONSTRATE THE TWO FIREFIGHTER FLAT RAISE FROM A LOW SHOULDER CARRY			
7	DEMONSTRATE THE ONE FIREFIGHTER LADDER RAISE FROM A LOW SHOULDER			
7 4	SECURE A RAISED LADDER			
	DEMONSTRATE THE TWO FIREFIGHTER LOW SHOULDER LADDER LIFE AND CARRY			
7 5	(FROM VERTICAL RACKING)			
9 1	PROPERLY BREAK ORDINARY PLATE GLASS			
9 2	USE AN ELECTRIC OR GASOLINE POWERED CIRCULAR SAW			
6 3	USE AN ELECTRIC RECIPROCATING SAW			
9 4	USE AN ELECTRIC OR GASOLINE POWERED CHAIN SAW			
9 2	FORCE AN OUT SWINGING DOOR			
9 6	FORCE AN IN SWINGING DOOR			
2 6	FORCE AN IN SWINGING DOOR (RABBETED JAMB)			
8 6	FORCE A CHECKRAIL (DOUBLE HUNG) WINDOW			
66	VENTILATE A PITCHED ROOF			
9 10	DEMONSTRATE MECHANICAL POSITIVE PRESSURE VENTILATION			
9 11	DEMONSTRATE MECHANICAL NEGATIVE PRESSURE VENTILATION			
9 12	DEMONSTRATE HYDRAULIC VENTILATION			
10 1	SAFELY MOUNI USE APPARATUS SAFETY EQUIPMENT AND DISMOUNT APPARATUS			

practical skills testing for Mandatory Fire Fighter in the State of Indiana This sheet should be used for the evaluation of the student, however, the Evaluator This check off sheet is intended to be used as a record of a student s performance of each skill listed. This sheet will serve as the permanent record of the should refer to the IDHS Practical Skills Book for additional guidance on the proper completion of the demonstrated skill REPORT ANY ERRORS OR PROBLEMS TO THE IDHS CERTIFICATION SECTION

LEAD EVALUATOR CERTIFICATION OF SKILLS

I certify that the student identified on this form has successfully completed all practical skills listed Falsification of this information may result in disciplinary action against the Instructor or Evaluator by the Board of Fire Fighter Personnel Standards and Education

DATE		PRINTED NAME
		2
		LEAD EVALUATOR
	SIGNED	Revised 7/06/06

DON AND DOFF ARTICLES OF PORTECTIVE CLOTHING/EQUIPMENT

Introduction

Because firefighters must often dress rapidly to respond to an alarm, they should learn to consistently don and doff their protective clothing in a set order. Not only does such a donning/doffing routine save time, but it also reduces the possibility of omitting an article of clothing such as gloves or hood. In addition, items placed in the turnout gear pockets should be placed in the same pocket each time so that the firefighter will not have to search through pockets to find the item in an emergency.

Equipment and Personnel

Helmet with faceshield

Hood

Instructor Name

Safety goggles Boots

Student Name

Gloves

Date

Turnout coat

Turnout trousers/suspenders

Job Steps	Key Points	PASS	FAIL
DONNING		-	
1 Don turnout trousers/suspenders.	1 a. Suspenders attached to trousers b. Shoes removed c. Trousers pulled on and fastened at		
	waist d. Suspenders adjusted over shoulders		
2 Don boots	2 Trouser legs over boots		
3 Don protective hood	3 a. Pulled down around neck and shoulders b. No exposed hair		
4 Don turnout coat	4 a. Closed completely b. Collar turned up		
5 Don safety goggles	5 Strap adjusted for comfort		
6 Don helmet	6 a. Strap adjusted under chin b. Faceshield lowered		
7 Don gloves	7 No exposed skin between coat cuff and glove		
DOFFING	•		
1 Doff gloves	Placed in turnout coat pocket		
2 Doff helmet	2 a. Chin strap loosened		
	b. Stored with front facing back of storage unit		
3 Doff safety goggles	3 Placed in turnout coat pocket or on storage shelf		
4 Doff protective hood	4 Placed in turnout coat pocket		
5 Doff turnout coat	5 a. Collar up and front completely unfastened b. Hung on storage hook		
6 Doff turnout trousers and boots	6 a. Suspenders removed from shoulders without loosening		
	b. Front flap unfastenedc. Trousers down around boot ankles,		
	suspenders to each side d. Stepped out of boots and trousers at same time		
	e. Placed boot/touser combination on floor under turnout coat, with boot toes facing back of storage unit	;	

DONNING SCBA FACE MASK (ATTACHED FACEPIECE-MOUNTED REGULATOR)

Introduction

SCBA must be stored ready to don. The backpack straps should be arranged so that they do not interfere with picking up the cylinder. You do not need to wear protective gloves when donning SCBA, but you should be wearing all other turnout gear, and your turnout coat should be fully fastened.

Equipment and Personnel

One firefighter in full protective clothing SCBA in case, regulator mounted in facepiece

Student Name

Instructor Name

Job Steps	Key Points	PASS	FAIL
DONNING THE CYLINDER			
1 Position and open the SCBA case	1 a. On clear, level surface		
	b. Out of traffic flow		
2 Crouch or kneel at end of case	2 End opposite cylinder valve		
3 Check cylinder guage	3 a. Reads at least 90% of rated ca		
	 b. Not in excess of rated capacity 	/	
4 Open cylinder valve	4 a. Slowly		
	b. Fully		
	Note: The low-pressure alarm		
	ring briefly. If it continues to ri		
	check the regulator valves. If		
	valves are closed and it contin		
	ring, close the cylinder valve, r		
	the unit from service, tag it, an	· .	
	an officer. If it does not ring, p		
	unit out of service as describe	d	
	above. Obtain another unit an	d begin	
	again at Step 1		
5 Crack the bypass valve	5 Removing unit from service ar	l l	
	notifying an officer if you do no	ot hear a	
	rush of air		
6 Close the bypass valve	6 Fully		
7 Check the regulator gauge	7 a. Reads within 100 psi of cylinde	er	
	gauge		
	b. Donning switch (if applicable)	in	
	DONNING mode		
8 Position the harness straps	8 a. To each side		
	b. Free of twists or tangles		
9 Grasp the backplate	9 a. At midpoint		
	b. One hand on each side		
	c. No straps between hands		
10 Tilt unit toward you.	10 a. Close to your body		
	b. Valve at top		
11 Stand up	11 a. Lifting with legs, not back		
	b. Unit held at waist level		
12 Lift the unit over your head	12 Elbows in		

Job Steps	Key Points	
13 Lower the unit down your back	13 a. Chin tucked in	
,	b. Leaning slightly forward	
	c. Elbows through straps	
	d. Backplate and straps sliding through	
	hands	
14 Grasp the ends of the shoulder straps	14 a. With hand on same side as strap	
'	b. With whole hand	
	c. Firmly	
15 Pull the shoulder straps	15 a. Downward and outward	
·	b. With quick jumping motion	
16 Fasten the chest strap (if applicable)		
17 Fasten and adjust the waist strap	17 Snug fit	
DONNING THE FACEPIECE		
18 Adjust your turnout gear	18 a. Helmet off* or on shoulder	
	b. Hood down around neck	
	*Note: Helmets with a breakaway	
	strap that completely disconnects may	
	be donned after the facepiece and	
	hood are in place	
19 Grasp the facepiece	19 a. With both hands	
	b. Harness at top	
	c. Thumbs through straps	
20 Spread the harness straps apart	20 a. With thumbs	
	b. Fully	
21 Position the facepiece	21 a. Firmly against face	
	b. Chin centered in cup	
22 Pull the harness into position	22 a. Moving hair out of seal area	
	b. Over top of head	
	c. Centered at back of head	
OO Dull the house of their	d. Untangled	
23 Pull the harness straps	23 a. Toward back of head	
	b. Evenly and simultaneously	
	c. Lower straps first	
	d. Temple straps next (if applicable)	
	e. Top strap last (if applicable) f. Snug but not too tight fit	
	Note: For a two-strap harness,	
	tighten the neck straps, and then	
	stroke the harness firmly down the	
	back of the head. Retighten the neck	
	straps as necessary.	
24 Close the cylinder valve	24 Fully	
25 Inhale to test facepiece seal	25 a. Slowly	
Lo milato to toot idoopiooo dodi	b. For 10 seconds	
	c. Retightening harness straps if mask	
	does not collapse against face	
26 Exhale to test the exhalation valve	26 a. Gentle exhalation	
Lo Extrato to toot the extratation valve	b. Repeating steps 19 through 25 if air	
	does not exit through exhalation valve.	
	acconst call anough candidation valve.	
27 Open the cylinder valve	27 Fully	
28 Inhale		
29 Press the facepiece to your face	29 a. With both hands	
l l l l l l l l l l l l l l l l l l l	b. Around seal area of facepiece	
30 Exhale	30 a. Gently*	
1	1	

Job Steps	Key Points	PASS	FAIL
	b. Removing facepiece from service if air does not exit through exhalation valve		
	*CAUTION: Exhale gently against a sealed facepiece in order to prevent possible damage to the inner ear from exhaling too forcefully.		
31 Test for positive pressure	31 a. Two fingers between mask and face b. Removing unit from service if air does not exit past fingers under pressure		
32 Reposition your protective hood	32 a. Head and neck completely covered b. Vision unobscured c. No part of hood between facepiece and face d. No hair showing		
33 Don the helmet	33 a. Earflaps down (if applicable) b. Firmly on head c. Chin strap adjusted firmly under chin		
34 Raise your coat collar	34 a. All the way around b. Fastened to closure (if applicable)		

DONNING SCBA FACE MASK (UNATTACHED FACEPIECE-MOUNTED REGULATOR)

Introduction

SCBA must be stored ready to don. The backpack straps should be arranged so that they do not interfere with picking up the cylinder. You do not need to wear protective gloves when donning SCBA, but you should be wearing all other turnout gear, and your turnout coat should be fully fastened.

Equipment One firefighter in full protective clothing and Personnel SCBA in case, regulator mounted to facepiece

Student Name

Instructor Name

Job Steps	Key Points	PASS	FAIL
DONNING THE CYLINDER			
1 Position and open the SCBA case	1 a. On clear, level surface		
1 1 conton and open the cob/t case	b. Out of traffic flow		
2 Crouch or kneel at end of case	2 End opposite cylinder valve		
3 Check cylinder gauge	3 a. Reads at least 90% of rated capaci	tv	
o oncon opiniuo, galago	b. Not in excess of rated capacity	, <u> </u>	
4 Open cylinder valve	4 a. Slowly		
,	b. Fully		
	Note: The low-pressure alarm sho	uld	
	ring briefly. It is continues to ring,		
	check the regulator valves. If both		
	valves are closed and it continues t	o	
	ring, close the cylinder valve, remov	/e	
	the unit from service, tag it, and not	-	
	an officer. If it does not ring, place	the	
	unit out of service as described		
	above. Obtain another unit and beg	gin	
	again at Step 1		
5 Crack the bypass valve	5 Removing unit from service and		
	notifying an officer if you do not hea	ır a	
	rush of air		
6 Close the bypass valve	6 Fully		
7 Check the regulator gauge	7 a. Reads within 100 psi of cylinder		
	gauge		
	b. Donning switch (if applicable) in		
O. Docition the horness atrong	DONNING mode 8 a. To each side		
8 Position the harness straps	b. Free of twists or tangles		
9 Grasp the backplate	9 a. At midpoint		
9 Grasp the backplate	b. One hand on each side		
	c. No straps between hands		
10 Tilt unit toward you	10 a. Close to your body		
. o The arm toward you	b. Valve at top		
11 Stand up and lift the unit	11 a. Lifting with legs, not back		
	b. Unit at waist level		
12 Lift the unit over your head	12 Elbows in		
13 Lower the unit down your back	13 a. Chin tucked in		
•	b. Leaning slightly forward		
	c. Elbows through straps		

Job Steps	Key Points	
·	d. Backplate and straps sliding through	
	hands	
14 Grasp the ends of the shoulder straps	14 a. With hand on same side as strap	
	b. With whole hand	
	c. Firmly	
15 Pull the shoulder straps	15 a. Downward and outward	
	b. With quick jumping motion	
16 Fasten the chest strap (if applicable)		
17 Fasten and adjust the waist strap		
DONNING THE FACEPIECE		
18 Adjust your turnout gear	18 a. Helmet off* or on shoulder	
	b. Hood down around neck	
	*Note: Helmets with a breakaway	
	strap that completely disconnects may	
	be donned after the facepiece and	
	hood are in place	
19 Grasp the facepiece	19 a. With both hands	
	b. Harness at top	
00.00	c. Thumbs through straps	
20 Spread the harness straps apart	20 a. With thumbs	
Of Decition the forces	b. Fully	
21 Position the facepiece	21 a. Firmly against face	
00 D Hill 1 22	b. Chin centered in cup	
22 Pull the harness into position	22 a. Moving hair out of seal area	
	b. Over top of head	
	c. Centered at back of head	
OO Dull the beauties at the con-	d. Untangled	
23 Pull the harness straps	23 a. Toward back of head	
	b. Evenly and simultaneously	
	c. Lower straps first	
	d. Temple straps next (if applicable)	
	e. Top strap last (if applicable)	
	f. Snug but not too tight fit Note: For a two-strap harness,	
	tighten the neck straps, and then	
	storoke the harness firmly down the	
	back of the head. Retighten the neck	
24 Insert the regulator into the facepiece	straps as necessary. 24 Seal obtained	
port.	24 Seal Obtained	
25 Inhale	25 a. Slowly	
2	b. For 10 seconds	
	c. Retightening harness straps if mask	
	does not collapse against face	
26 Exhale to test the exhalation valve	26 a. Gentle exhalation	
	b. Repeating steps 19 through 25 if air	
	does not exit through exhalation valve.	
	J	
27 Open the cylinder valve	27 Fully	
28 Inhale	28 a. Slowly	
	b. For 10 seconds	
29 Press the facepiece to your face	29 a. With both hands	
. ,	b. Around seal area of facepiece	
30 Exhale	30 a. Gently*	
	b. Removing facepiece from service if air	
	does not exit through exhalation valve	
	ĭ l	

Job Steps	Key Points	PASS	FAIL
	*CAUTION: Exhale gently against a sealed facepiece in order to prevent possible damage to the inner ear from exhaling too forcefully.		
31 Test for positive pressure	31 a. Two fingers between mask and face b. Removing unit from service if air does not exit past fingers under pressure		
32 Reposition your protective hood	 32 a. Head and neck completely covered b. Vision unobscured c. No part of hood between facepiece and face d. No hair showing 		
33 Don the helmet	33 a. Earflaps down (if applicable) b. Firmly on head c. Chin strap adjusted firmly under chin		
34 Raise your coat collar	34 a. All the way aroundb. Fastened to closure (if applicable)c. Not in excess of rated capacity		

DON SCBA BACKPACK USING CROSSED-ARMS OR REGULAR COAT METHOD

Introduction

This job sheet is divided into two parts, each part outlining the steps for donning the SCBA like a coat. Part 1 provides instructions for donning the SCBA using the crossed-arms method. This method requires that equipment be arranged so that both shoulder straps can be grasped for lifting. Part 2 provides instructions for donning the SCBA using the regular coat method in which the firefighter puts one arm at a time through the shoulder strap loops. This method requires that the unit be arranged so that either shoulder strap can be grasped for lifting.

Equipment and Personnel

One firefighter in full protective clothing

SCBA backpack

Student Name

Instructor Name

Job Steps	Key Points	PASS	FAIL
DONNING THE BACKPACK (CROSSED-ARMS			
1 Position and open the SCBA case	1 a. On clear, level surface		
	b. Out of traffic flow		
2 Crouch or kneel at end of the case	End opposite cylinder valve		
3 Check cylinder guage	3 a. Reads at least 90% of rated capac	ty	
	b. Not in excess of rated capacity		
4 Open the cylinder valve	4 a. Slowly		
	b. Fully		
	Note: The low-pressure alarm sho	uld	
	ring briefly. It is continues to ring,		
	check the regulator valves. If both		
	valves are closed and it continues	:o	
	ring, close the cylinder valve, remo	ve	
	the unit from service, tag it, and no	tify	
	an officer. If it does not ring, place	the	
	unit out of service as described		
	above. Obtain another unit and be	gin	
	again at Step 1		
5 Crack the bypass valve	5 Removing unit from service and		
	notifying an officer if you do not hear a		
	rush of air		
6 Check the regulator gauge	6 a. Reads within 100 psi of cylinder		
	gauge		
	b. Donning switch (if applicable) in		
	DONNING mode		
7 Kneel, or bend down, and grasp the	7 a. Arms crossed left over right		
shoulder straps	b. At top of harness		
	c. Left hand holding left strap; right ha	and	
	holding right strap		
	Note: The next two steps should b	e	
	performed in one smooth motion		
8 Stand up and lift the unit.	8 Lifting with legs, not back		
9 Swing unit around right shoulder	9 a. While raising left arm		
	b. Bringing unit behind head and onto		
	back		
	c. Straps sliding through hands to the		
	buckles		

Job Steps
Note: Depending upon your physique, it may be more comfortable to fasten the chest buckle (Step 12) before tightening the shoulder straps. 11 Pull the shoulder straps to adjust. 12 Fasten the chest strap (if applicable) 13 Fasten and adjust the waist strap. 14 Don the facepiece 15 Following method in Job Sheet 3-1 or 3-1a appropriate to your unit 16 DONNING THE BACKPACK (REGULAR COAT METHOD) 1 Position and open the SCBA case. 1 a. On clear, level surface b. Out of traffic flow 2 Crouch or kneel at the end of the case. 3 Check the cylinder gauge. 3 a. Should read at least 90% of rated capacity 4 Open the cylinder valve. 4 a. Slowly b. Fully Note: The low-pressure alarm should ring briefly. It is continues to ring, check both regulator valves. If both valves are closed and the bell coontinues to ring, close the cylinder valve, remove the unit from service, tag it, and notify an officer. If it does not ring, place the unit out of service as described above. Obtain another unit, and begin again at Step 1 5 Crack the bypass valve. 5 Crack the bypass valve. 6 Check the bypass valve. 6 Check the bypass valve. 6 Check the bypass valve.
chest buckle (Step 12) before tightening the shoulder straps. 11 Pull the shoulder straps to adjust. 12 Fasten the chest strap (if applicable) 13 Fasten and adjust the waist strap. 14 Don the facepiece 15 Position and open the SCBA case. 16 Check the bypass valve. 17 Casten the cylinder valve. 18 Downward and outward b. With quick jumping motion 19 With quick jumping motion 10 With quick jumping motion 11 A. Downward and outward b. With quick jumping motion 12 Fasten the chest strap (if applicable) 13 Fasten and adjust the waist strap. 14 Following method in Job Sheet 3-1 or 3-1a appropriate to your unit 14 Following method in Job Sheet 3-1 or 3-1a appropriate to your unit 15 Crack the cylinder Case. 16 Check the straps (if applicable) 17 Following method in Job Sheet 3-1 or 3-1a appropriate to your unit 18 Following method in Job Sheet 3-1 or 3-1a appropriate to your unit 19 Con clear, level surface b. Out of traffic flow 2 Crouch or kneel at the end of the case. 2 At the same end as cylinder valve 3 Should read at least 90% of rated capacity 4 Open the cylinder valve. 4 Slowly b. Fully Note: The low-pressure alarm should ring briefly. It is continues to ring, check both regulator valves are closed and the bell coontinues to ring, close the cylinder valve, remove the unit from service, tag it, and notify an officer. If it does not ring, place the unit out of service as described above. Obtain another unit, and begin again at Step 1 10 Forack the bypass valve. 10 Forack the bypass valve. 11 A. Downward and outward b. With quick jumping motion 12 Forack the dead the service and notifying an officer if you do not hear a rush of air. 18 Forack the bypass valve. 19 Forack the double of the case. 20 At the same end as cylinder walve. 21 At the same end as cylinder walve. 22 At the same end as cylinder walve. 23 Check the cylinder valve. 24 At the same end as cylinder the planting
the shoulder straps. 11 Pull the shoulder straps to adjust. 11 a. Downward and outward b. With quick jumping motion 12 Fasten the chest strap (if applicable) 13 Fasten and adjust the waist strap. 14 Pon the facepiece 14 Following method in Job Sheet 3-1 or 3-1a appropriate to your unit DONNING THE BACKPACK (REGULAR COAT METHOD) 1 Position and open the SCBA case. 2 Crouch or kneel at the end of the case. 3 Check the cylinder gauge. 3 a. Should read at least 90% of rated capacity b. Not in excess of rated capacity 4 Open the cylinder valve. 4 a. Slowly b. Fully Note: The low-pressure alarm should ring briefly. It is continues to ring, check both regulator valves. If both valves are closed and the bell coontinues to ring, close the cylinder valve, remove the unit from service, tag it, and notify an officer. If it does not ring, place the unit out of service as described above. Obtain another unit, and begin again at Step 1 5 Crack the bypass valve. 5 Removing unit from service and notifying an officer if you do not hear a rush of air. 6 Check the bypass valve. 6 a. Should read within 100 psi of cylinder gauge
11 Pull the shoulder straps to adjust. 12 Fasten the chest strap (if applicable) 13 Fasten and adjust the waist strap. 14 Don the facepiece 15 Pollowing method in Job Sheet 3-1 or 3-1 a appropriate to your unit polyment of the strate of the strate of the strate of the strate of all polyment of the strate of all polyment of the strate of the strategies of t
b. With quick jumping motion 12 Fasten the chest strap (if applicable) 13 Fasten and adjust the waist strap. 14 Following method in Job Sheet 3-1 or 3-1a appropriate to your unit DONNING THE BACKPACK (REGULAR COAT METHOD) 1 Position and open the SCBA case. 1 a. On clear, level surface b. Out of traffic flow 2 Crouch or kneel at the end of the case. 3 Check the cylinder gauge. 3 a. Should read at least 90% of rated capacity b. Not in excess of rated capacity 4 Open the cylinder valve. 4 a. Slowly b. Fully Note: The low-pressure alarm should ring briefly. It is continues to ring, check both regulator valves. If both valves are closed and the bell coontinues to ring, close the cylinder valve, remove the unit from service, tag it, and notify an officer. If it does not ring, place the unit out of service as described above. Obtain another unit, and begin again at Step 1 5 Crack the bypass valve. 5 Removing unit from service and notifying an officer if you do not hear a rush of air. 6 Check the bypass valve. 5 Sould read within 100 psi of cylinder gauge
12 Fasten the chest strap (if applicable) 13 Fasten and adjust the waist strap. 14 Don the facepiece 14 Following method in Job Sheet 3-1 or 3-1a appropriate to your unit DONNING THE BACKPACK (REGULAR COAT METHOD) 1 Position and open the SCBA case. 1 a. On clear, level surface b. Out of traffic flow 2 Crouch or kneel at the end of the case. 2 At the same end as cylinder valve 3 Check the cylinder gauge. 3 a. Should read at least 90% of rated capacity b. Not in excess of rated capacity 4 Open the cylinder valve. 4 a. Slowly b. Fully Note: The low-pressure alarm should ring briefly. It is continues to ring, check both regulator valves. If both valves are closed and the bell coontinues to ring, close the cylinder valve, remove the unit from service, tag it, and notify an officer. If it does not ring, place the unit out of service as described above. Obtain another unit, and begin again at Step 1 5 Crack the bypass valve. 5 Removing unit from service and notifying an officer if you do not hear a rush of air. 6 Check the bypass valve. 6 a. Should read within 100 psi of cylinder gauge
13 Fasten and adjust the waist strap. 14 Following method in Job Sheet 3-1 or 3-1 a appropriate to your unit DONNING THE BACKPACK (REGULAR COAT METHOD) 1 Position and open the SCBA case. 2 Crouch or kneel at the end of the case. 3 Check the cylinder gauge. 4 Open the cylinder valve. 5 Crack the bypass valve. 5 Crack the bypass valve. 1 Snug fit Following method in Job Sheet 3-1 or 3-1 a appropriate to your unit Following method in Job Sheet 3-1 or 3-1 appropriate to your unit Following method in Job Sheet 3-1 or 3-1 appropriate to your unit Following method in Job Sheet 3-1 or 3-1 appropriate to your unit Following method in Job Sheet 3-1 or 3-1 appropriate to your unit Following method in Job Sheet 3-1 or 3-1 appropriate to your unit Following method in Job Sheet 3-1 or 3-1 appropriate to your unit Following method in Job Sheet 3-1 or 3-1 appropriate to your unit Following method in Job Sheet 3-1 or 3-1 appropriate to your unit Following method in Job Sheet 3-1 or 3-1 appropriate to your unit Following a supplied to your unit Following a scriptor table to your unit Following a scriptor table to your unit Following appropriate to your appropriate to your unit Following appropriate to your appropriate to your unit Following appropriate to your appropriate to your unit
14 Following method in Job Sheet 3-1 or 3-1a appropriate to your unit DONNING THE BACKPACK (REGULAR COAT METHOD) 1 Position and open the SCBA case. 1 a. On clear, level surface b. Out of traffic flow 2 Crouch or kneel at the end of the case. 3 Check the cylinder gauge. 3 a. Should read at least 90% of rated capacity b. Not in excess of rated capacity b. Fully Note: The low-pressure alarm should ring briefly. It is continues to ring, check both regulator valves. If both valves are closed and the bell coontinues to ring, close the cylinder valve, remove the unit from service, tag it, and notify an officer. If it does not ring, place the unit out of service as described above. Obtain another unit, and begin again at Step 1 5 Crack the bypass valve. 5 Removing unit from service and notifying an officer if you do not hear a rush of air. 6 Check the bypass valve. 6 a. Should read within 100 psi of cylinder gauge
3-1a appropriate to your unit DONNING THE BACKPACK (REGULAR COAT METHOD) 1 Position and open the SCBA case. 1 a. On clear, level surface b. Out of traffic flow 2 Crouch or kneel at the end of the case. 3 Check the cylinder gauge. 3 a. Should read at least 90% of rated capacity b. Not in excess of rated capacity b. Fully Note: The low-pressure alarm should ring briefly. It is continues to ring, check both regulator valves. If both valves are closed and the bell coontinues to ring, close the cylinder valve, remove the unit from service, tag it, and notify an officer. If it does not ring, place the unit out of service as described above. Obtain another unit, and begin again at Step 1 5 Crack the bypass valve. 5 Removing unit from service and notifying an officer if you do not hear a rush of air. 6 Check the bypass valve. 6 Check the bypass valve. 6 Check the bypass valve.
DONNING THE BACKPACK (REGULAR COAT METHOD) 1 Position and open the SCBA case. 2 Crouch or kneel at the end of the case. 3 Check the cylinder gauge. 3 a. Should read at least 90% of rated capacity b. Not in excess of rated capacity b. Not in excess of rated capacity b. Fully Note: The low-pressure alarm should ring briefly. It is continues to ring, check both regulator valves. If both valves are closed and the bell coontinues to ring, close the cylinder valve, remove the unit from service, tag it, and notify an officer. If it does not ring, place the unit out of service as described above. Obtain another unit, and begin again at Step 1 5 Crack the bypass valve. 5 Removing unit from service and notifying an officer if you do not hear a rush of air. 6 Check the bypass valve. 6 a. Should read within 100 psi of cylinder gauge
1 Position and open the SCBA case. 2 Crouch or kneel at the end of the case. 3 Check the cylinder gauge. 3 Check the cylinder valve. 4 Open the cylinder valve. 4 Open the cylinder valve. 4 Open the cylinder valve. 5 Fully Note: The low-pressure alarm should ring briefly. It is continues to ring, check both regulator valves. If both valves are closed and the bell coontinues to ring, close the cylinder valve, remove the unit from service, tag it, and notify an officer. If it does not ring, place the unit out of service as described above. Obtain another unit, and begin again at Step 1 5 Crack the bypass valve. 5 Check the bypass valve. 6 Check the bypass valve. 6 a. Should read within 100 psi of cylinder gauge
b. Out of traffic flow 2 Crouch or kneel at the end of the case. 3 Check the cylinder gauge. 3 a. Should read at least 90% of rated capacity b. Not in excess of rated capacity 4 Open the cylinder valve. 4 a. Slowly b. Fully Note: The low-pressure alarm should ring briefly. It is continues to ring, check both regulator valves. If both valves are closed and the bell coontinues to ring, close the cylinder valve, remove the unit from service, tag it, and notify an officer. If it does not ring, place the unit out of service as described above. Obtain another unit, and begin again at Step 1 5 Crack the bypass valve. 5 Removing unit from service and notifying an officer if you do not hear a rush of air. 6 Check the bypass valve. 6 a. Should read within 100 psi of cylinder gauge
2 Crouch or kneel at the end of the case. 3 Check the cylinder gauge. 3 a. Should read at least 90% of rated capacity b. Not in excess of rated capacity 4 Open the cylinder valve. 4 a. Slowly b. Fully Note: The low-pressure alarm should ring briefly. It is continues to ring, check both regulator valves. If both valves are closed and the bell coontinues to ring, close the cylinder valve, remove the unit from service, tag it, and notify an officer. If it does not ring, place the unit out of service as described above. Obtain another unit, and begin again at Step 1 5 Crack the bypass valve. 5 Removing unit from service and notifying an officer if you do not hear a rush of air. 6 Check the bypass valve. 6 a. Should read within 100 psi of cylinder gauge
3 a. Should read at least 90% of rated capacity b. Not in excess of rated capacity 4 Open the cylinder valve. 4 a. Slowly b. Fully Note: The low-pressure alarm should ring briefly. It is continues to ring, check both regulator valves. If both valves are closed and the bell coontinues to ring, close the cylinder valve, remove the unit from service, tag it, and notify an officer. If it does not ring, place the unit out of service as described above. Obtain another unit, and begin again at Step 1 5 Crack the bypass valve. 5 Crack the bypass valve. 6 Check the bypass valve. 6 a. Should read within 100 psi of cylinder gauge
capacity b. Not in excess of rated capacity 4 a. Slowly b. Fully Note: The low-pressure alarm should ring briefly. It is continues to ring, check both regulator valves. If both valves are closed and the bell coontinues to ring, close the cylinder valve, remove the unit from service, tag it, and notify an officer. If it does not ring, place the unit out of service as described above. Obtain another unit, and begin again at Step 1 5 Crack the bypass valve. 5 Removing unit from service and notifying an officer if you do not hear a rush of air. 6 Check the bypass valve. 6 a. Should read within 100 psi of cylinder gauge
b. Not in excess of rated capacity 4 a. Slowly b. Fully Note: The low-pressure alarm should ring briefly. It is continues to ring, check both regulator valves. If both valves are closed and the bell coontinues to ring, close the cylinder valve, remove the unit from service, tag it, and notify an officer. If it does not ring, place the unit out of service as described above. Obtain another unit, and begin again at Step 1 5 Crack the bypass valve. 5 Removing unit from service and notifying an officer if you do not hear a rush of air. 6 Check the bypass valve. 6 a. Should read within 100 psi of cylinder gauge
4 a. Slowly b. Fully Note: The low-pressure alarm should ring briefly. It is continues to ring, check both regulator valves. If both valves are closed and the bell coontinues to ring, close the cylinder valve, remove the unit from service, tag it, and notify an officer. If it does not ring, place the unit out of service as described above. Obtain another unit, and begin again at Step 1 5 Crack the bypass valve. 5 Removing unit from service and notifying an officer if you do not hear a rush of air. 6 Check the bypass valve. 6 a. Should read within 100 psi of cylinder gauge
b. Fully Note: The low-pressure alarm should ring briefly. It is continues to ring, check both regulator valves. If both valves are closed and the bell coontinues to ring, close the cylinder valve, remove the unit from service, tag it, and notify an officer. If it does not ring, place the unit out of service as described above. Obtain another unit, and begin again at Step 1 5 Crack the bypass valve. 5 Removing unit from service and notifying an officer if you do not hear a rush of air. 6 Check the bypass valve. 6 a. Should read within 100 psi of cylinder gauge
Note: The low-pressure alarm should ring briefly. It is continues to ring, check both regulator valves. If both valves are closed and the bell coontinues to ring, close the cylinder valve, remove the unit from service, tag it, and notify an officer. If it does not ring, place the unit out of service as described above. Obtain another unit, and begin again at Step 1 5 Crack the bypass valve. 5 Removing unit from service and notifying an officer if you do not hear a rush of air. 6 Check the bypass valve. 6 a. Should read within 100 psi of cylinder gauge
ring briefly. It is continues to ring, check both regulator valves. If both valves are closed and the bell coontinues to ring, close the cylinder valve, remove the unit from service, tag it, and notify an officer. If it does not ring, place the unit out of service as described above. Obtain another unit, and begin again at Step 1 5 Crack the bypass valve. 5 Removing unit from service and notifying an officer if you do not hear a rush of air. 6 Check the bypass valve. 6 a. Should read within 100 psi of cylinder gauge
check both regulator valves. If both valves are closed and the bell coontinues to ring, close the cylinder valve, remove the unit from service, tag it, and notify an officer. If it does not ring, place the unit out of service as described above. Obtain another unit, and begin again at Step 1 5 Crack the bypass valve. 5 Removing unit from service and notifying an officer if you do not hear a rush of air. 6 Check the bypass valve. 6 a. Should read within 100 psi of cylinder gauge
valves are closed and the bell coontinues to ring, close the cylinder valve, remove the unit from service, tag it, and notify an officer. If it does not ring, place the unit out of service as described above. Obtain another unit, and begin again at Step 1 5 Crack the bypass valve. 5 Removing unit from service and notifying an officer if you do not hear a rush of air. 6 Check the bypass valve. 6 a. Should read within 100 psi of cylinder gauge
coontinues to ring, close the cylinder valve, remove the unit from service, tag it, and notify an officer. If it does not ring, place the unit out of service as described above. Obtain another unit, and begin again at Step 1 5 Crack the bypass valve. 5 Removing unit from service and notifying an officer if you do not hear a rush of air. 6 Check the bypass valve. 6 a. Should read within 100 psi of cylinder gauge
valve, remove the unit from service, tag it, and notify an officer. If it does not ring, place the unit out of service as described above. Obtain another unit, and begin again at Step 1 5 Crack the bypass valve. 5 Removing unit from service and notifying an officer if you do not hear a rush of air. 6 Check the bypass valve. 6 a. Should read within 100 psi of cylinder gauge
tag it, and notify an officer. If it does not ring, place the unit out of service as described above. Obtain another unit, and begin again at Step 1 5 Crack the bypass valve. 5 Removing unit from service and notifying an officer if you do not hear a rush of air. 6 Check the bypass valve. 6 a. Should read within 100 psi of cylinder gauge
not ring, place the unit out of service as described above. Obtain another unit, and begin again at Step 1 5 Crack the bypass valve. 5 Removing unit from service and notifying an officer if you do not hear a rush of air. 6 Check the bypass valve. 6 a. Should read within 100 psi of cylinder gauge
as described above. Obtain another unit, and begin again at Step 1 5 Crack the bypass valve. 5 Removing unit from service and notifying an officer if you do not hear a rush of air. 6 Check the bypass valve. 6 a. Should read within 100 psi of cylinder gauge
unit, and begin again at Step 1 5 Crack the bypass valve. 5 Removing unit from service and notifying an officer if you do not hear a rush of air. 6 Check the bypass valve. 6 a. Should read within 100 psi of cylinder gauge
5 Crack the bypass valve. 5 Removing unit from service and notifying an officer if you do not hear a rush of air. 6 Check the bypass valve. 6 a. Should read within 100 psi of cylinder gauge
notifying an officer if you do not hear a rush of air. 6 Check the bypass valve. 6 a. Should read within 100 psi of cylinder gauge
rush of air. 6 Check the bypass valve. 6 a. Should read within 100 psi of cylinder gauge
6 Check the bypass valve. 6 a. Should read within 100 psi of cylinder gauge
gauge
7 Position the SCBA for donning. 7 a. Harness straps spread to sides
b. Upper portion of straps over top of
backplate
8 Kneel, or bend down, and grasp the left 8 a. Top of strap with left hand
harness strap. b. Lower portion of same strap with right
hand
Note: The next two steps should be
performed in one smooth motion
9 Stand up 9 Lifting with legs, not back
10 Swing the unit around your left shoulder 10 a. Left arm through left shoulder strap
b. Bringing unit behind head and onto
back
c. Right hand released
d. Right arm inserted through right
shoulder strap
e. Straps sliding through hands to the
j e. Otrapa anung tritough handa to the j j

Job Steps	Key Points	PASS	FAIL
11 Grasp the ends of the shoulder straps.	11 a. With hand on same side as strap		
Note: Depending upon your physique, it	b. With whole hand		
may be more comfortable to fasten the	c. Firmly		
chest buckle (step 13) before tightening			
the shoulder straps.			
12 Pull the shoulder straps to adjust.	12 a. Downward and outward		
	b. With quick jumping motion		
13 Fasten the chest strap (if appplicable).			
14 Fasten and adjust the waist strap.	14 Snug fit.		
15 Don the facepiece.			

DON COMPARTMENT OR BACK UP-MOUNTED SCBA BACKPACK

Introduction

SCBA stored in a closed compartment can be ready for rapid donning by using any number of mounts. A mount on the inside of a compartment presents the same advantages as does side-mounted equipment. The backup mount provides quick access to SCBA. The following is the basic procedure for donning SCBA using the backup method. There may be slight variations for mounts from which the SCBA can be donned while seated.

Equipment and Personnel

One firefighter in full protective clothing Compartment - or backup-mounted SCBA

Student Name

Instructor Name

ob Steps	Key F	Points	PASS	FAIL
1 Uncover the SCBA	T		1	
2 Remove the facepiece and place it nearby		Safe location		
2 hemove the racepiece and place it hearby	Ι.	_		
3 Check the cylinder gauge.		Lens up Should ready at least 90% of rated		
5 Offeck the cylinder gauge.	3 a.			
		capacity		
4. On an the endinder value		Not in excess of rated capacity		
4 Open the cylinder valve.		Slowly		
	b.	Fully Note: The low-pressure alarm should		
		ring briefly. It is continues to ring,		
		check the regulator valves. If both		
		valves are closed and it continues to		
		ring, close the cylinder valve, remove		
		the unit from service, tag it, and notify		
		an officer. If it does not ring, place the		
		unit out of service as described		
		above. Obtain another unit and begin		
5 O and the beautiful a	├ _	again at Step 1		
5 Crack the bypass valve	5	Removing unit from service and		
		notifying an officer if you do not hear a		
0.01	<u> </u>	rush of air		
6 Check the regulator gauge	6 a.	Reads within 100 psi of cylinder		
	Ι.	gauge		
	b.	Donning switch (if applicable) in		
	<u> </u>	DONNING mode		
7 Position yourself for donning		Back at cylinder backplate		
		Arms through harness straps		
0.0 : 11		Hands grasping straps at shoulders		
8 Quickly step forward	8	Unit cleared from mount		
9 Slide your hands down, and grasp the end		With whole hand		
of the shoulder straps.		Firmly		
10 Pull the shoulder straps to adjust.		Downward and outward		
		With quick jumping motion		
4. =	C.	Leaning slightly forward		
11 Fasten the chest buckle (if applicable).		-		
12 Fasten and adjust the waist strap.	12	Snug fit		
13 Don the facepiece	13	Following method in Job Sheet 3-1 or		
		3-1a appropriate to your unit		

CLEAN AND INSPECT AN SCBA UNIT (AFTER USE)

Introduction

SCBA undergoes rough use. It is frequently exposed to temperature extremes and damp conditions. Inspection and cleaning after each use is essential in keeping the apparatus in top operating condition.

Equipment and Personnel

One firefighter in full protective clothing

SCBA

Cleaner-disinfectant solution recommended by manufacturer

Soft, lint-free towels

2 buckets, one for wash solution and one for clear rinse water

Drying rack

Student Name

Instructor Name

Job Steps	Key Points

ANING/SANITIZING		PASS	FA
1 Submerge the facepiece and low-	1 a. Warm water		
pressure hose.	b. Approved cleaner-disi	nfectant solution	
2 Wash the facepiece.	2 a. Inside and out		
	b. With soft towel		
3 Dunk the facepiece.	3 a. Up and down.		
	 b. Until exhalation valve i 	is clean	
4 Rinse the facepiece and low-pressure	4 a. In clean, warm water		
hose.	b. Dunking up and down		
	c. Thoroughly		
5 Dry the facepiece and low-pressure hose.	5 a. Thoroughly		
	b. With clean, soft, lint-fro	l l	
	 c. Components hung on 	drying rack to	
	completely air dry		
	Note: For proper air p	l l	
	operation, it is <i>very im</i>	•	
	hose interior be compl	· · · · · · · · · · · · · · · · · · ·	
6 Wipe the entire unit.	6 a. With approved cleaner	r-disinfectant	
	b. With clean, soft towel		
	 c. Until cleaned and deod 		
7 Wipe the carrying case or mounting area.	7 a. With approved cleane	r-disinfectant	
	b. With clean, soft towel		
	 c. Until cleaned and deod 	dorized	
8 Wash and rinse the harness if necessary	8 a. With mild soap or com	nmercial	
	cleaning agent		
	b. With clean, soft cloth		
	c. Thoroughly, until clear	ned and	
	sanitized		
9 Hang the harness.	9 a. Out of sunlight		
	b. To air dry		
10 Reassemble and inspect the unit.	10 After all components a	re thoroughly	
	dry		

ob Steps	Key F	Points	PASS	FAIL
NSPECTION				
Note: If your inspection reveals damage				
or missing parts, notify an officer, red tag				
the unit, and place it out of service				
1 Check the cylinder pressure.	1 a.	At least 90 percent full		
	b.	Pressure breathed off from high-		
		pressure system		
		CAUTION: The bypass should never		
		be used to exhaust pressure unless		
		the manufacturer specifically allows		
		you to do so.		
2 Open the cylinder valve to check	2 a.	Cylinder and regulator gauges within		
operation of gauges and low-pressure		100 psi of each other.		
alarm.	b.	Low-pressure alarm sounds briefly		
3 Check the high-pressure and low-	3 a.	O-rings, gaskets, and screens (in		
pressure hose connections.		place and undamaged)		
	b.	Connections (tight; no leaks)		
4 Check the condition of the low-pressure	4	Stretched (no cracks)		
hose.				
5 Visually inspect the condition of the		No drying		
facepiece material.		No cracks		
		Clean		
6 Visually inspect the condition of the	1	No excessive scratches		
facepiece lens.		No cracks or separation from mask		
7 Visually inspect the exhalation valve and valve seat.	7	Clean (no foreign material)		
8 Visually inspect the diaphragm.	8 a	Flexible		
o riodany mopeot are diaprilagini		No small holes		
	1	Clean (no foreign material)		
9 Check the high-pressure hose.		No wrinkles		
3 1	b.	No excessive wear		
	c.	No tears		
10 Check the harness system.	10 a.	Undamaged		
·		Straps fully extended		
11 Open and close the mainline and bypass	11	Briefly		
valves to check operation.				
12 Store the unit.	12	According to local protocol		

CONDUCTING A PRIMARY SEARCH

Introduction

The primary search is the first and most dangerous. It is a quick attempt to locate any potential victims who are in danger. The primary search should be as thorough as time and conditions permit.

Equipment and Personnel

At least two firefighters dressed in full protective clothing and SCBA

Forcible Entry Tool

Flashlight Radio

Students Name

Instructors Name

Job Steps	Key Points	PASS	FAIL
1 Start your SCBA airflow.	All members of team CAUTION: A safety officer will check your gear before you enter the structure. Make sure that no skin or hair is exposed!		
2 Position yourselves.	2 a. At entrance but out of doorway b. Force entry into structure		
3 The search team is often ahead of the attack lines and may be above the fire.			
4 Each room should be searched using a standard pattern.	4 a. Follow walls around the perimeter b. Reach toward the middle of the room to feel for victims c. Use handle of tool to extend reach d. Right hand/left hand-pick a direction and stick to it. e. Stay in contact with each other at all times f. Maintain voice communications at all times		
5 The search team may encounter closed doors.	5 Check the temperature of the door to determine if there is active fire on the other side before opening		
6 Upon completion of search.	6 a. Exit structure as team b. Report to command search complete		

RESTRICTED OPENING REMOVAL

Introduction During fire fighting operations, it may become necessary to remove SCBA and proceed through a

restricted opening. In this job sheet, you learn how to remove your SCBA, proceed through restricted

opening and reapply your SCBA.

Equipment and Personnel

Two firefighters in full protective clothing including SCBA

d Personnel 3' X 3' square opening

Black out mask or waxed paper

Hose line

Students Name

Instructors Name

Job Steps	Key Points	PASS	FAIL
	•		
1 Two firefighters in full protective clothing	1 a. Wearing SCBA		
	b. Breathing air		
2 Follow hose line 6' to restricted opening	2 a. SCBA mask blacked out		
	b. Staying low as there may be super		
	heated air		
3 Doff SCBA	3 a. Do not remove gloves		
4 Loosen straps	4 a. Completely		
5 Release chest strap (if applicable)			
6 Remove SCBA from back	6 a. Be careful to maintain seal on mask		
7 Place SCBA on the floor and push	7 a. Do not remove SCBA mask		
through restricted opening and follow by	b. Be careful to maintain seal on SCBA		
proceeding through opening	mask		
8 Advance along floor for 6'	8 a. Pushing SCBA in front of firefighter		
	following hose line		
9 Don SCBA	9 a. Making sure to tighten all straps		
10 Position the SCBA for donning.	10 a. Harness straps spread to sides		
	b. Upper portion of straps over top of		
	backplate		
11 Kneel, or bend down, and grasp the left	11 a. Top of strap with left hand		
harness strap.	b. Lower portion of same strap with right		
	hand		
12 Swing the unit around your left shoulder	12 a. Left arm through left shoulder strap		
	b. Bringing unit behind head and onto		
	back		
	c. Right hand released		
	d. Right arm inserted through right		
	shoulder strap		
	e. Straps sliding through hands to the		
	buckles		
13 Grasp the ends of the shoulder straps.	13 a. With hand on same side as strap		
Note: Depending upon your physique, it	b. With whole hand		
may be more comfortable to fasten the	c. Firmly		
chest buckle before tightening the			
shoulder straps.			

Job Steps	Key Points	PASS	FAIL
14 Pull the shoulder straps to adjust.	14 a. Downward and outward		
	b. With quick jumping motion		
15 Fasten the chest strap (if appplicable).			
16 Fasten and adjust the waist strap.	16 Snug fit.		

DEMONSTRATE TECHNIQUES FOR ACTION WHEN TRAPPED OR **DISORIENTED**

Introduction It is imperative that the firefighter learn the correct safety procedures for exiting the fire area or

summoning help when disoriented or trapped in a burning building. Procedures should be practiced

routinely, and in the sequence listed below, until they become second nature.

Equipment and Personnel One firefighter in full protective clothing, SCBA, and PASS

Dark plastic bag to fit over SCBA facepiece

Two-story building, or training area having several rooms and halls

Coupled lengths of hose advanced to "fire" area

Students Name

Instructors Name

Date

Job Steps	Key Points		
WHEN DISORIENTED		PASS	FAIL
WHEN DISORIENTED		PASS	FAIL
1 Remain calm.	1 a. Stopping all movement		·

EN DISORIENTED			PASS	FAI
1 Remain calm.	1 a.	Stopping all movement		
	b.	Breathing normally		
	С.	Thinking		
2 Try to retrace your steps.	2 a.	Finding hoseline		
	b.	Following direction of male coupling		
		toward exit		
	С.	Remaining low		
	d.	Descending stairs face toward top		
3 Make radio contact if retracing your steps	3 a.	Describing your locations as		
in ineffective.		accurately as possible		
4 Shout for help or bang on something to	4 a.	Loudly		
attract attention if a hoseline cannot be	b.	Moving in direction of response		
located or you cannot make radio contact.		NOTE: The SCBA facepiece makes it		
		difficult to shout loudly, but the		
		facepiece should not be removed.		
		Shouting also uses up oxygen faster		
		than normal speech. Unless you		
		know that other firefighters are very		
		near, reserve shouting for a last		
		resort.		

WHEN TRAPPED

WILLI THAFFLD			
1 Remain calm.	1 a.	Stopping all movement	
	b.	Breathing normally	
	c.	Thinking	
2 Activate your PASS device.	2	Depressing manual switch	
3 Try to establish radio contact if your PASS	3	Describing your locations as	
signal goes unheeded.		accurately as possible	
4 Shout for help or bang on something to	4 a.	Loudly	
attract attention if your PASS signal brings		NOTE: The SCBA facepiece makes it	
no response and you cannot establish		difficult to shout loudly, but the	
radio contact.		facepiece should not be removed.	
		Shouting also uses up oxygen faster	
		than normal speech. Unless you	
		know that other firefighters are very	
		near, reserve shouting for a last	
		resort.	

USE A HYDRAULIC SPREADER

Introduction

The following job steps provide general procedures for operating a hydraulic spreader. Be thoroughly familiar with the tool, its operating principles, methods, and limitations. *ALWAYS read and follow the manufacturer's directions and cautions before powering or operating a tool.*

CAUTION: Before powering or operating the following tool, you MUST be dressed in full protective clothing and wearing safety goggles under your lowered faceshield.

Equipment and Personnel

Two firefighters (one to operate the spreader and one to operate a hand-operated hydraulic pump if used) in full protective clothing and helmets with faceshields

Safety goggles

Vehicle-mounted, portable motor-driven, or hand-operated hydraulic pump

Hydraulic spreader

Wrecked automobile(s) or other object(s) appropriate for skill demonstration

Students Name

Instructors Name

Steps	Key F	Points	PASS	FA
ACEDURE FOR ROWERING ORDERS WITH	A	TOMATIO LIVERALILIO BUME		
OCEDURE FOR POWERING SPREADER WIT 1 Check the condition of the hydraulic		Gaskets in good condition or replaced		
hoses and components.	' a.	as necessary		
noses and components.	۱ ہ			
2 Position the hydraulic pump.		Hoses undamaged in any way Outside work area		
2 Position the hydraulic pump.		Within reach of spreader's hydraulic		
	b.	hoses		
	l c.	Close enough to permit work to be		
		accomplished without stretching		
		hoses.		
3 Adjust your protective clothing.	3 a.	Safety goggles on		
, , ,		Faceshield lowered		
		Gloves on		
4 Connect the spreader's hydraulic hoses to		To outlets on hydraulic pump		
the power source.		Snug connections		
5 Pick up the spreader		One hand on each arm handle or one		
о и от при		hand on arm handle and one on top		
		bar grip		
	l ь.	Hydraulic lines over shoulder or to		
		side and behind you		
6 Operate the button on top of the spreader	6 a.	In "close" direction		
to close the spreader		With thumb (both hands on spreader		
ээ энээ энэ эргээлээ.	l ь.	handles)		
		Until arms are fully closed		
7 Insert the arms into the object to be		Tips only		
spread or compressed.		142 29		
CAUTION: Keep both hands on spreader	l ь.	At proper angle for desired effect		
handles and away from work to avoid				
crushing injury.				
8 Operate button on top of spreader to open	8 a.	In "open" direction		
the spreader		With thumb (both hands on spreader		
,		handles)		
	c.	Until desired compresson or		
	"	separation is achieved		

ob Steps		Points	PASS	FAIL
9 Close the spreader arms.	9	Per Step 6		
10 Remove the spreader from the work				
11 Disconnect the spreader from its power source	11	Per manufacturer's instructions		
12 Return the tool to proper storage.	12 a.	Hydraulic hoses connected		
		Per manufacturer's instructions and		
		department protocol		
ROCEDURE FOR POWERING SPREADER WI'	тн ма	• •	BY SECO	DND
Note: It is recommended that a manually	Ι			
operated hydraulic pump be used only if				
an automatic pump is not available.				
1 (Spreader Operator) Check the condition	1 a.	Gaskets in good condition or replaced		
of the spreader's hydraulic hoses and		as necessary		
components.	b.	Hoses undamaged in any way		
2 (Pump Operator) Position the hydraulic		Inside work area		
pump.	b.	Out of way of spreader operator		
		Within reach of hydraulic lines		
		Close enough to permit work to be		
		accomplished without stretching		
		hoses.		
3 (Both Firefighters) Adjust your protective	3 a.	Safety goggles on		
clothing		Faceshield lowered		
5.54 m.lg		Gloves on		
4 (Spreader Operator) Connect the		To outlets on hydraulic pump		
spreader's hydraulic hoses to power source.		Snug connections		
5 Pick up the spreader	_{5 a}	One hand on each arm handle or one		
o i lok up the opteader	° u.	hand on arm handle and one on top		
		bar grip		
	h	Hydraulic lines over shoulder or to		
	5.	side and behind you		
6 (Pump Operator) Turn the base lever on	6	Counterclockwise		
the hydraulic pump.	"	Counterclockwise		
7 Pump the hydraulic pump lever to close the spreader arms.	7 a.	Up and down		
•	b.	Until spreader operator signals that		
	"	arms are fully closed		
8 (Spreader Operator) Insert spreader arms	8 a.	Tips only		
into object to be spread or compressed.		At proper angle for desired effect		
CAUTION: Keep both hands on spreader	1	· · · · · · · · · · · · · · · · · · ·		
handles and away from work to avoid				
crushing injury.				
9 (Pump Operator) Turn the base lever on	9	Clockwise		
the hydraulic pump.				
10 Pump the hydraulic pump lever to open	10 a	Up and down		
the spreader arms.		Until spreader operator signals that		
ano oproduci aimo.	5.	desired compression or separation is		
		achieved		
11 Repeat Steps 6 through 10.	11	Until desired cuts have been made		
12 Close the spreader arms.	12	-		
	14	Per Steps 6 and 7		
13 (Spreader Operator) Remove the				
spreader from the work.				

USE HYDRAULIC SHEARS

Introduction

The following job steps provide general procedures for operating a hydraulic shears. Be thoroughly familiar with the tool, its operating principles, methods, and limitations. *ALWAYS read and follow the manufacturer's directions and cautions before powering or operating a tool.*

CAUTION: Before powering or operating the following tool, you MUST be dressed in full protective clothing and wearing safety goggles under your lowered faceshield.

Equipment and Personnel

Two firefighters (one to operate the shears and one to operate a hand-operated hydraulic pump if

used) in full protective clothing and helmets with faceshields

Safety goggles

Vehicle-mounted, portable motor-driven, or hand-operated hydraulic pump

Hydraulic shears

Wrecked automobile(s) or other object(s) appropriate for skill demonstration

Students Name

Instructors Name

Job Steps	Key P	oints	PASS	FAIL
PROCEDURE FOR POWERING SHEARS WITH A	AUTO	MATIC HYDRAULIC PUMP		
1 (Shears Operator) Check the condition of	1 a.	Gaskets in good condition or replaced		
the hydraulic hoses and components.		as necessary		
	b.	Hoses undamaged in any way		
2 (Pump Operator) Position the hydraulic	2 a.	Outside work area		
pump.	b.	Within reach of shears' hydraulic		
		hoses		
	С.	Close enough to permit work to be		
		accomplished without stretching		
		hoses.		
3 (Both Firefighters) Adjust your protective	3 a.	Safety goggles on		
clothing.	b.	Faceshield lowered		
		Gloves on		
4 (Shears Operator) Connect the shears'	4 a.	To outlets on hydraulic pump		
hydraulic hoses to the power source.		Snug connections		
5 Pick up the shears	5 a.	One hand on handle arm		
		Other hand on top bar grip		
	С.	Hydraulic lines over shoulder or to		
		side and behind you		
6 (Pump Operator) Operate the button on		In "open" direction		
top of the shears to open the shears.		With thumb (both hands on handles)		
		Until blades are fully open		
7 Grasp the work to be cut with the shear	7 a.	Work well back in blades		
blades				
CAUTION: Keep both hands on shear	b.	At proper angle for desired cut		
handles and away from work to avoid				
cutting/crushing injury.				
8 (Shears Operator) Operate the button on	8 a.	In "close" direction		
top of the shears to close the shears.		With thumb (both hands on shear		
	b.	handles)		
	c.	Until desired cut is made		
9 (Pump Operator) Repeat Steps 6 through	9			
8.		To make additional cuts as necessary		
10 Remove the shears from the work.				

o Steps		Points	PASS	FAIL
11 Close the shear blades	11	Per Step 8		
12 (Shears Operator) Disconnect the shears	12	Per manufacturer's instructions		
from their power source.				
13 Return the tool to proper storage.	13 a	Hydraulic hoses connected		
To rictain the tool to proper storage.		Per manufacturer's instructions and		
	J 5.			
		department protocol		
OCEDURE FOR POWERING SHEARS WITH	MANU	ALLY OPERATED HYDRAULIC PUMP		
Note: It is recommended that a manually	_			
operated hydraulic pump be used only if				
an automatic pump is not available.				
1 (Shears Operator) Check the condition of	1 a	Gaskets in good condition or replaced		
the shears' hydraulic hoses and	' ".	- · · · · · · · · · · · · · · · · · · ·		
		as necessary		
components.		Hoses undamaged in any way		
2 (Pump Operator) Position the hydraulic		Inside work area		
pump.		Out of way of shears operator		
		Within reach of hydraulic lines		
	d.	Close enough to permit work to be		
		accomplished without stretching		
		hoses.		
3 (Both Firefighters) Adjust your protective	3 a.	Safety goggles on		
clothing	b.	Faceshield lowered		
Q	c.	Gloves on		
4 (Shears Operator) Connect the shears'		To outlets on hydraulic pump		
hydraulic hoses to power source.		Snug connections		
5 Pick up the shears		One hand on handle arm		
5 Fick up the shears		Other hand on top bar grip		
	C.	Hydraulic lines over shoulder or to		
	 	side and behind you		
6 (Pump Operator) Turn the base lever on	6	Clockwise		
the hydraulic pump.				
7 Pump the hydraulic pump lever to open	7 a.	Up and down		
the shear arms.	b.	Until shears operator signals that		
		arms are fully opened		
8 (Shears Operator) Grasp the work to be	8 a.	Work well back in blades		
cut with the shear blades.		At proper angle for desired cut		
	5.	7 tt proper ungle for desired out		
CAUTION: Keep both hands on shear				
handles and away from work to avoid				
cutting/crushing injury.	 			
9 (Pump Operator) Turn the base lever on	9	Counterclockwise		
the hydraulic pump.				
10 Pump the hydraulic pump lever to close		Up and down		
the blades.	b.	Until shears operator signals that the		
		desired cut is made		
11 Repeat Steps 6 through 10.	11	Until desired cuts have been made		
12 (Shears Operator) Remove the shears				
from the work. 13 Disconnect the shears from their power	13	Per manufacturer's instructions		
source.	13	i di manufacturer s instructions		
14 Return the tool to proper storage.	14 a.	Hydraulic hoses connected		
		Per manufacturer's instructions and		
				i e

BUILDING A BOX CRIB

Introduction The following job steps provide general procedures for building a box crib.

Equipment and Personnel

object.

One or two firefighters in full protective clothing and helmets with faceshields

Safety goggles

Cribbing

Students Name

Instructors Name

Date

Job Steps	Key Points	PASS	FAIL
PROCEDURE FOR BUILDING A BOX CRIB			
1 Gather cribbing to be used.	1 a. May be found on emergency vehicle		
	carrying extrication equipment		
2 Adjust your protective clothing.	2 a. Safety goggles on		
	b. Faceshield lowered		
	c. Gloves on		
4 Build box out of cribbing overlaping only	4 a. Build under object to be stabilized		
on the ends.			
5 Build as high a necessary to stabilize	5 a. Use wedges where necessary to		

make contact with vehicle

USE THE TWO-FIREFIGHTER METHOD TO COUPLE HOSE

Key Points

Introduction

The effective use of hoselines is the foundation of a firefighter's work. It is critical that you

comprehend and perform all hose work automatically and with precision. Two people can quickly and

PASS

FAIL

efficiently couple hose.

Equipment and Personne

Job Steps

Two firefighters in protective clothing

and Personnel Two lengths of hose

Students Name

Instructors Name

•	
1 Position the hoses	Male and female couplings facing each other
2 Position yourselves.	2 a. Holding opposite couplings b. Facing each other
3 (Firefighter with male coupling) Cradle male coupling.	3 a. Tightly against upper thigh or midsection b. Firmly with both hands c. Hands directly behind coupling d. Hose slightly bent directly behind coupling e. Threads facing outward f. Not looking at coupling Note: Firefighter with the male coupling looks away so as not to interfere with the alignment. The hose must be aligned by the firefighter with the female coupling.
(Firefighter with female coupling)	
4 Inspect the couplings.	4 a. Gasket b. Threads c. Shape d. Obstructions
5 Set the threads.	5 a. Holding female coupling firmly in both hands b. Bringing female coupling to male coupling
6 Connect the couplings.	c. Aligning Higbee indicator 6 a. Turning swivel clockwise with thumb b. Until hand tight

DEMONSTRATE A BASIC STRAIGHT HOSE ROLL

Introduction

The straight hose roll is generally used for hose that is going to be put in storage - especially rack storage - returned to quarters for washing, or loaded back on the apparatus at the fire scene. When the roll is completed, the female end is exposed, with the male end protected in the center of the roll.

A variation of this method is to begin the roll at the female coupling so that when the roll is completed, the male coupling is exposed. This is often done to denote a damaged coupling or piece of hose. A tag is usually attached to the male coupling indicating the type and location of the damage.

Equipment and Personnel

One firefighter Section of hose

Students Name

Instructors Name

Job Steps	Key Points	PASS	FAIL
1 Lay out the hose.	1 a. On clean surface		
	b. Flat		
	c. Straight line		
	d. Without twisting		
2 Position yourself for rolling.	2 At male coupling		
3 Begin the roll.	3 a. Male coupling rolled over onto hose		
_	b. Toward female end		
	c. Forming coil open enough to allow		
	fingers to be inserted for carrying		
4 Complete the roll.	4 a. Rolling coupling along hose toward		
·	female end.		
	b. Keeping edges aligned		
	c. Not rolling over female coupling		
5 Reposition roll.	5 a. When completely rolled to female		
·	coupling		
	b. Laying on ground		
6 Align any protruding coils.	6 a. Tamping down into roll with your foot		
	b. Gently		

DEMONSTRATE A TWO-PERSON DONUT HOSE ROLL

Introduction

The donut roll has certain advantages that the straight roll does not possess. Two main advantages are that both ends are available on the outside of the roll and that the hose is less likely to spiral or kink when unrolled. Its adaption to service makes it a preferred hose roll in many instances. When a section of fire hose needs to be rolled into a donut roll, one or two firefighters may perform the task. This job sheet outlines the procedure for a two-firefighter donut roll.

Equipment and Personnel

Two firefighters Section of hose

Students Name

Instructors Name

Job Steps	Key Points	PASS	FAIL
1 Lay out the hose.	1 a. On clean surface		
	b. Flat		
	c. Straight line		
	d. Without twisting		
2 Pick up the hose.	By male coupling		
3 Carry the hose.	3 a. Toward female coupling		
4 Position the male coupling.	4 a. On top of hose		
	b. 6 feet (2 m) from female coupling		
	c. Lapped over smoothly		
	c. Without kinks		
5 Take positions.	5 a. First firefighter at fold facing female		
	coupling		
	b. Second firefighter 4 to 5 feet (1.2 m to		
	1.5 m) in front of and facing first		
(First firefighter)			
6 Start the roll.	6 a. Toward couplings		
	b. Hand over hand		
	c. Leaving sufficient center loop for		
	carrying		
(Second Firefighter)			
7 Remove slack and keep the hose straight	7 a. Walking backwards		
	b. During rolling		
	c. Not rolling over couplings		
8 Reposition the roll.	8 a. Laying flat		
	b. On ground		
9 Complete the roll.	9 a. Bringing female end around male end		
	b. To protect male coupling		

PERFORM A STREET DRAG

Introduction The street drag is another method for advancing hose at ground level. This method is used when

personnel resources are short as it requires few firefighters.

In addition, by placing the hose over both shoulders with the couplings on the chest and pulling, a dual-

line drag can be used to advance two lines simultaneously.

Equipment One firefighter in protective clothing

and Personnel One section of 2 1/2-inch (65 mm) fire hose

Students Name

Instructors Name

Job Steps	Key Points	PASS	FAIL
	•		
1 Position the hose.	1 a. In a straight line		
	b. Flat		
	c. Couplings placed gently		
2 Position yourself.	2 a. At one end of hose		
	b. To one side		
	c. Facing direction of travel		
3 Pick up the hose.	3 a. Just behind coupling		
	b. With hand nearest hose		
4 Advance.	4 a. Toward opposite end of hose.		
	b. To approximate center of hose		
5 Pick up the hose.	5 a. At center point		
	b. With free hand		
6 Place the hose over your shoulder.	6 a. Shoulder nearest hose		
	b. Flat and untwisted		
7 Step to other side of hoseline.	7 Permitting hose to cross your chest		
8 Advance.	8 To next coupling		
9 Pick up the coupling.	9 With free hand		
10 Drag the hose.	10 a. Gripping hose just behind couplings		
	b. 20 feet (6 m)		
11 Lay the hose down.	11 a. On ground		
	b. Placing couplings gently		

INSPECT, CLEAN, AND DRY HOSE

Introduction

The importance of reliable fire hose is sometimes not fully appreciated, and hose that has been neglected is more likely to fail when operted than hose that has been maintained in peak condition. Undependable hose can also be responsible for serious injury to firefighters and others. The techniques for washing and drying fire hose and the provisions for storage are very important functions.

Equipment

One firefighter

and Personnel Stiff-bristled scrub brushes

Broom Wire brush

Warm water and mild soap or detergent solution

Charged booster hose/nozzle Used hose to be cleaned

Hose machine detergent recommended by manufacturer

Cabinet-type hose machine

Hose drying tower, rack, or cabinet

Students Name

Instructors Name

ob Steps	Key Points	PASS	FAIL
AND CLEANING			
1 Clean the coupling swivels.	1 a. Submerging in warm, soapy water		
	b. Working forward and backward		
	c. Until free of dirt and other foreign		
	matter		
2 Clean the male threads.	2 a. With stiff-bristled scrub brush or wire		
	brush		
	b. Until free of clogged tar, asphalt, or		
	other foreign material		
3 Inspect hose couplings.			
4 Brush the length of the hose.	4 a. With broom		
	b. Until free of accumulated dust and dirt		
5 Wash areas of the hose that contain dirt not removed by brushing.	5 With booster hose and clear water		
6 Scrub the hose.	6 a. Areas that have been exposed to oil		
	or grease		
	b. With scrub brush and mild soap or		
	detergent		
	c. Until all oil or grease is removed		
7 Rinse the hose.	7 a. Thoroughly		
	b. With clear water from booster hose		
8 Inspect the hose.	8 a. For any remaining grease or oil stains		
·	, , , , , , , , , , , , , , , , , , , ,		
	b. For frayed, snagged, or worn areas		

Job Steps	Key Po		PASS	FAIL
9 Dry the hose.	9 a. (Out of the sun		
	b. l	Jsing one of the following methods:		
		Hanging in hose tower		
		Placing on drying rack		
		Placing in hose dryer cabinet		
	l 1	Note: If drying the hose in a hose		
		drying cabinet, set the thermostat to		
		the drying temperature recommended		
		by the cabinet manufacturer.		
	`	by the capinet manufacturer.		
10 Roll and store the hose.	1	After it has dried		
	b. F	Per department SOP		
JSING HOSE WASHING MACHINE	14. (3b		
1 Clean the coupling swivels.		Submerging in warm, soapy water		
		Working forward and backward		
	1	Until free of dirt and other foreign		
		matter		
2 Clean the male threads.	2 a. \	With stiff-bristled scrub brush or wire		
	k	orush		
	b. l	Until free of clogged tar, asphalt, or		
		other foreign material		
3 Inspect hose couplings.				
4 Connect the hose washing machine	4 a. 7	To pumper or hydrant		
supply line.	b. F	Per manufacturer's instructions		
5 Place dirty hose in hose bin.	5 a. F	Rolled		
	b. F	Per manufacturer's instructions		
6 Open the front of the machine and thread	6 a. E	Between brushes and rollers		
the hose into the machine	b. F	Per manufacturer's instructions		
7 Secure the hose.		To hose roller		
	b. F	Per manufacturer's instructions		
8 Add detergent if necessary.	8 /	Amount and type recommended by		
,		manufacturer		
9 Turn on the machine.		First shutting front door		
		Per manufacturer's instructions		
10 Inspect the hose.		When wash cycle is complete		
To mopost and model		or any remaining grease or oil stains		
	~	groups or any remaining groups or an elamic		
	c. F	or frayed, snagged, or worn areas		
11 Dry the hose.		Out of the sun		
•	b. l	Jsing one of the following methods:		
		By hanging in hose tower		
		By placing in drying rack		
		By placing in hose dryer cabinet		
		Note: If drying the hose in a hose		
		drying cabinet, set the thermostat to		
		the drying temperature recommended		
		by the cabinet manufacturer.		
		by the cabillet manufacturer.		
10 Roll and store the hose.	10 a. A	After it has dried		
	l h F	Per department SOP		

INSPECT HOSE COUPLINGS AND REPLACE A HOSE GASKET

Introduction

Before any piece of equipment is placed on the apparatus, it should be in top operating condition. Hose couplings are vital for attaching hose to other hose and nozzles. If they or their gaskets are damaged, they can hinder the mission and endanger firefighters' lives.

Equipment and Personnel

One firefighter in protective clothing

Hoses with male, female, and Storz couplings

Replacement gaskets of appropriate types and sizes

Students Name

Instructors Name

Job Steps	Key Points	PASS	FAIL
NSPECT HOSE COUPLINGS			
	1 a. Tight on hose or appliance	1	
1 Inspect the male couplings.			
	b. Undamaged threads c. Not out of round		
	d. Free of burrs		
O leavest the female as all as	e. Clean		
2 Inspect the female couplings.	2 a. Tight on hose or appliance		
	b. Undamaged threads		
	c. Not out of round		
	d. Free of burrs		
	e. Clean		
	f. Free-spinning swivel		
	g. Swivel gasket undamaged, pliable,		
	and clean		
	h. Swivel gasket in place		
3 Inspect the Storz couplings.	3 a. Tight on hose or appliance		
	b. Not edged		
	c. Free of burrs		
	d. Clean		
	e. Free-spinning swivel		
	f. Swivel gasket undamaged and clean		
	g. Swivel gasket in place		
	h. Undamaged connecting lugs		
REPLACE A HOSE GASKET	, , , , , , , , , , , , , , , , , , , ,		
1 Remove old or damaged gasket.	Discard in proper receptacle		
2 Pick up new gasket.	2 a. Between middle finger and thumb		
	b. Index finger on inside rim		
3 Fold outer rim upward.	3 With index finger		
4 Place gasket into swivel	4 a. Large loop first		
•	b. Smoothing as necessary to seat		

ACCORDION LOAD AND UNLOAD HOSE

Introduction

The accordion load places bends at each end of the hose bed, but it has an added feature of having all

flakes the same length. This feature is a distinct advantage in hoseline advancement.

Because all of the folds in an accordion load are nearly the same length, they can be easily loaded on the shoulder by taking several folds at a time directly from the hose bed.

Equipment and Personnel

Two firefighters in protective clothing

Hose bed

Four lengths of coupled fire hose

Students Name

Instructors Name

lob Steps	Key Points	PASS	FAIL
OAD			
1 Inspect the couplings.			
2 Position yourselves for loading.	2 One firefighter at either end of h	ose	
	bed		
	Note: If available, a third firefigl	nter on	
	the ground can feed the hose to	the	
	two in the bed.		
3 Start the load.	3 a. Male coupling for forward lay		
	b. Female coupling for reverse lay		
4 Place coupling in the hose bed.	4 Any corner of bed per departme	ent	
	Note: In a split hose bed, the he	ose	
	coupling is usually placed near		
	center hose bed divider at the re	l l	
	the apparatus, with female cour		
	hanging below the hose bed so	•	
	can later be placed on top of the		
	in the adjacent bed.	11000	
5 Stand hose on edge in hose bed.	5 a. Starting at coupling		
	b. Extending hose full length of be	d 🗀	
6 Fold back (loop) the hose	6 a. When front or rear of bed is rea		
· · · /	b. Toward opposite end of bed		
	c. Tight fold		
	d. Hose remaining on side, untwis	ted	
7 Continue until a coupling is reached.	7 a. Each succeeding fold full length		
	bed		
	b. On edge		
	c. Back and forth		
	d. Packing tightly and neatly		
8 Stagger couplings in the hose bed to	8 a. Avoiding side-by-side couplings		
allow for easy removal of the hose.	b. Using entire hose bed		
-	c. Couplings not interfering with fo	lds	

Job Steps	Key F	Points	PASS	FAIL
9 Use a "dutchman" (a short fold or reverse	9 a.	Per department SOP		
bend) to position couplings for proper exit.	b.	Changing direction of hose		
	С.	Changing location of coupling		
	d.	Coupling will pull straight out without		
		having to turn around		
10 Continue loading hose.		Using same methods		
	b.	Until all hose is loaded		
	c.	Until hose bed comoplement is		
		reached		
	d.	Until hose bed is full		
UNLOAD				
 Position yourself for unloading 		Facing hose bed		
		Opposite nozzle or coupling		
2 Grasp the hose.	2 a.	Nozzle or coupling and number of		
		folds needed to make up load		
		With both hands		
3 Pull several folds out of bed.		As many as are needed		
		About one-third out		
4 Place the hose folds on your shoulder.		In one smooth action		
		Twisting folds into upright position		
		Turning away from bed		
		Pivoting into folds		
5 Adjust the load as necessary	5 a.	Hose is flat on shoulder		
	b.	Hose is balanced on shoulder		
		Nozzle or coupling is in front of you		
6 Secure load on your shoulder.		Grasping with both hands each side		
		Tightly		
7 Step away from the apparatus.	7	Pulling load completely out of bed		
8 Remove additional shoulder loads.	8	In the same manner		

FLAT LOAD AND UNLOAD HOSE

Introduction

The flat load, as the name implies, consists of folding the hose back and forth on its flat sides,

lengthwise in the hose compartment. The load places approximately the same number of bends in the hose as the accordion load, and it has the same added feature of having all the flakes the same

length.

Due to the way flat and horseshoe loads are arranged in the hose bed, it is necessary to load one

section of hose at a time onto the shoulder.

Equipment and Personnel

Two firefighters in protective clothing

Hose bed

Four lengths of coupled fire hose

Students Name

Instructors Name

Job Steps	Key Points	PASS	FAIL
-OAD			
1 Inspect the couplings.			
2 Position yourselves for loading.	2 One firefighter at either end of	hose	
	bed		
	Note: If available, a third firefig	hter on	
	the ground can feed the hose to	o the	
	two in the bed.		
3 Start the load.	3 a. Male coupling for forward lay		
	b. Female coupling for reverse lay	/	
4 Place coupling in the hose bed.	4 Any corner of bed per departme	ent	
	SOP		
	Note: The hose coupling is usu	ıally	
	placed near the center hose be	d	
	divider at the rear of the appara	atus.	
5 Lay the hose in the hose bed.	5 a. Starting at coupling		
•	b. In front-to-back or back-to-front	t T	
	fashion		
	c. Flat and parallel to hose bed or	divider	
	·		
6 Make folds (loops).	6 a. At front and rear of hose bed		
	b. Side by side (lengths of hose		
	alongside each other)		
	c. Tight		
	d. Until tier is full		
7 Stagger couplings in the hose bed to	7 a. Avoiding side-by-side couplings	3	
allow for easy removal of the hose.	b. Using entire hose bed		
•	c. Couplings not interfering with fo	olds	
8 Use a "dutchman" (a short fold or reverse	8 a. Per department SOP		
bend) to position couplings for proper exit	b. Changing direction of hose		
	c. Changing location of coupling		
	d. Coupling will pull straight out wi	ithout	
	having to turn around		

Job Steps	Key Points	PASS	FAIL
9 Start second (and subsequent) tier.	9 a. By folding hose back to beginning side		
10 Stagger the folds of each tier.	10 a. Shortening alternate tier folds b. Approximately 4 inches (100 mm) from front and back Note: One tier full lengths, next tier 4 inches (100 mm) short front and back, next tier full engths, and so on to permit the center of the load to fill evenly.		
UNLOAD	·		
1 Position yourself for unloading	1 a. On ground b. Facing hose bed		
2 Remove the nozzle from the hose bed.	2 a. Pulling out and over either shoulder b. Nozzle facing down c. Midpoint of back		
3 Grasp hose for unloading.	3 a. Hand crossed over chest to hold over- shoulder hoseline b. Other arm slipped through long hose loops to shoulder c. Hand of same arm grasping short loops		
4 Unload the hose.	4 a. Pulling hose clear of bed b. Turning away from hose bed c. Walking away from apparatus d. Both hands on hoseline at nozzle shoulder.		

PERFORM A SHOULDER LOOP HOSE CARRY

Introduction

The shoulder loop hose carry is one method of carrying a single section of hose. When forming the shoulder loops, the firefighter must take care not to form the loops so long that they present a tripping hazard.

Equipment and Personnel

One firefighter in protective clothing One length of 2 1/2-inch (65 mm) hose

Students Name

Instructors Name

Job Steps	Key Points	PASS	FAIL
1 Position the hose.	1 a. In a straight line		
	b. Flat		
	c. Couplings placed gently		
2 Position yourself.	2 a. At one end of hose		
	b. Facing opposite end		
3 Place the hose over your shoulder.	3 a. Coupling (or nozzle) in back		
	b. Hanging down at waist		
	c. Hoseline directly in front of body		
4 Form a bight in the hose.	4 a. About 3 feet (1 m) long		
	b. On ground		
	c. By stepping forward		
5 Loop the bight over your shoulder	5 a. In one smooth movement		
	b. Holding hose at shoulder with one		
	hand		
	c. Stooping and picking up hose with		
	other hand		
	d. Rising and bringing hose back over		
	shoulder		
	e. Loop hanging just short of ground		
	CAUTION: Do not make loops so		
	long that you will catch your feet in		
	them when carrying the hose.		
6 Repeat Steps 4 and 5.	6 Until length of hose is shoulder loaded		
7 Place the load on your opposite shoulder.	7 a. Grasping hose at shoulder		
	b. Lifting flaked loop from shoulder		
	c. Pivoting toward loop		
	d. Inserting free arm through loop		
	e. Settling loop on shoulder		
8 Carry the hose.	8 20 feet (6 m)		
9 Lay the hose down.	9 a. On ground		
,	b. Couplings (nozzle) placed gently		

OPERATE A FOG STREAM NOZZLE

Introduction

The design of most fog nozzles permits adjustment of the fog tip to produce different stream patterns from the nozzle. In order to produce an effective fire stream with a fog nozzle, the firefighter must be able to quickly adjust the nozzle to the appropriate fog pattern and pressure for the fire situation. Although nozzle designs differ, the water pattern produced by the nozzle setting affects the ease with which the nozzle may be handled. Also, once the nozzle pressure is sufficient to produce a satisfactory reach, further increases in nozzle pressure only cause the stream to break up and be difficult to handle.

Equipment and Personnel

One driver/operator
One pumper

Two firefighters in protective clothing, one at nozzle and one for backup Pump-connected hoseline equipped with adjustable gallonage fog nozzle

Targets

Students Name

Instructors Name

ob Steps	Key Points	PASS	FAIL
1 Position yourselves	1 a. Same side of hose		
	b. One firefighter on nozzle; or	ne as	
	backup		
2 Adjust the gallonage output.	2 a. Depressing and releasing la	atch with	
	thumb if applicable.		
	b. Twisting gallonage adjustment		
O. A.P. and the state of the st	c. To gpm indicated by instruc		
3 Adjust the stream pattern.	3 a. Twisting stream adjustment	ring	
4 Alma Haranana	b. To a straight stream	2124	
4 Aim the nozzle.	4 At target indicated by instru		
5 Open the nozzle	5 a. Pushing bale fully forward,	• • • • • •	
	trigger, or turning shank to	open"	
	position as applicable		
	b. While advancing to within s	tream	
	reach		
6 Hold the stream on target.	6 For 15 seconds		
7 Shut off the water flow.	7 Releasing bale or trigger, or	r twisting	
	stream ring as applicable		
8 Repeat steps 2 through 7.	8 a. At different gallonage settin	• — —	
	b. Until technique becomes co	omfortable	
	and automatic		
ARROW FOG STREAM			
1 Position yourselves.	1 a. Same side of hose		
	b. One firefighter on nozzle; or	ne as	
	backup		
2 Adjust the gallonage output.	2 a. Depressing and releasing la	atch with	
	thumb if applicable		
	b. Twisting gallonage adjustment		
	c. To gpm indicated by instruc		
3 Adjust the stream pattern.	3 a. Twisting stream adjustment	t ring	
	b. To a narrow fog stream		
4 Aim the nozzle.	4 At target indicated by instru	ctor	

Job Steps	Key Points	PASS	FAIL
5 Open the nozzle	5 a. Pushing bale fully forward, sque trigger, or turning shank to "ope	<u> </u>	
	position as applicable	"'	
	b. While advancing to within strea	m	
	reach		
6 Hold the stream on target.	6 For 15 seconds		
7 Shut off the water flow.	7 Releasing bale or trigger or twis	sting	
	the "shut off" position as applica	able	
8 Repeat steps 2 through 7.	8 a. At different gallonage settings		
	b. Until technique becomes comfo	rtable	
	and automatic		
WIDE FOG STREAM			
1 Position yourselves.	1 a. Same side of hose		
	b. One firefighter on nozzle; one a	s	
	backup		
2 Adjust the gallonage output.	2 a. Depressing and releasing latch	with	
	thumb if applicable		
	b. Twisting gallonage adjustment	ring	
	c. To gpm indicated by instructor		
3 Adjust the stream pattern.	3 a. Twisting stream adjustment ring	9	
	b. To a wide fog stream		
4 Aim the nozzle.	4 At target indicated by instructor		
5 Open the nozzle	5 a. Pushing bale fully forward, sque	- 1	
	trigger, or turning shank to "ope	en"	
	position as applicable		
	b. While advancing to within strea	m	
	reach		
6 Hold the stream on target.	6 For 15 seconds		
7 Shut off the water flow.	7 Releasing bale or trigger or twis	•	
	the "shut off" position as applica	able	
8 Repeat steps 2 through 7.	8 a. At different gallonage settings		
	b. Until technique becomes comfo	ortable	
	and automatic		

OPERATE A SOLID STREAM NOZZLE

Introduction

A solid stream is produced from a fixed orifice, smoothbore nozzle; therefore, the stream pattern cannot be adjusted. Pressure is adjusted at the pumper. For handlines, pressure should be 50 psi (350 kPa), plus adjustment for friction loss; for master stream devices, pressure should be 80 psi (560 kPa), plus adjustment for friction loss.

The solid stream nozzle is designed to produce a stream as compact as possible, with little shower or spray. This type of stream is capable of reaching areas that might not be reached by other streams. Solid streams also minimize the steam burn hazard associated with fog streams.

Equipment and Personnel

One driver/operator

One pumper

Two firefighters in protective clothing, one at nozzle and one for backup Pump-connected hoseline equipped with adjustable gallonage fog nozzle

Targets

Students Name

Instructors Name

Job Steps	Key Points	PASS	FAIL
1 Position yourselves	1 a. Same side of hose b. One firefighter on nozzle; one as backup		
2 Aim the nozzle.	At target indicated by instructor		
3 Open the nozzle	3 a. Pulling bale backward b. slowly c. While advancing to within stream reach		
4 Hold the stream on target.	4 For 15 seconds		
5 Shut off the water flow.	5 a. Pushing bale forward b. Slowly		
6 Repeat steps 2 through 5.	6 a. On targets at different ranges and elevations b. Until technique becomes comfortable		
	and automatic		

MAKE SOFT-SLEEVE HYDRANT CONNECTION

Introduction

When hydrant connections are made from a reverse lay, the intake hose is soft sleeve. Soft-sleeve hose is more flexible than hard-suction hose. Because of this, soft-sleeve connections are easier to perform and require fewer personnel.

Equipment and Personnel

One apparatus driver/operator

One firefighter to make the hydrant connection

Soft-sleeve hose

Spanner or hydrant wrench

Rubber mallet

4 1/2-inch (115 mm) to 2 1/2-inch (65 mm) reducer coupling (if hydrant has only 2 1/2-inch (65 mm)

outlets)

Students Name

Instructors Name

b Steps	Key Points	PASS	FAIL
1 Spot the pumper.	1 a. At convenient angle to hydrant outlet b. Within limits of intake hose length c. Pump intake a few feet short of hydrant outlet		
2 Close the booster tank valve.	2 If there is no clapper between pump and tank		
3 Remove the pump intake cap.	3 a. Turning counterclockwise b. Using mallet or spanner if tight		
4 Remove necessary equipment from the pumper.	4 a. Hydrant or spanner wrench b. Reducer (if necessary) c. Rubber mallet		
5 Remove the hydrant caps.	5 a. Turning counterclockwise b. Using spanner wrench if cap is tight		
6 Inspect the hydrant.	6 a. Exterior for damage b. Inside outlet for debris or damage		
7 Place the hydrant wrench on hydrant nut.	7 Handle pointing away from outlet		
8 Place the adapter on the hydrant.	8 a. Reducer, if necessary b. Turning clockwise c. Hand tight		
9 Remove the intake hose from the pumper.			
10 Inspect the intake hose coupling.			
11 Connect the intake hose to the pump intake. Note: Some departments carry the soft-	11 a. Turning clockwise b. Until hand tight		
sleeve hose preconnected to the pump intake through a gated intake valve. This arrangement requires only that the soft-			
sleeve intake hose be stretched to the hydrant.			
12 Stretch the intake hose to the hydrant.			
13 To aid in establishing connection without kinking hose move the apparatus if necessary	13 Slightly		
14 Inspect the intake hose coupling.			

Job Steps	Key Points	PASS	FAIL
15 Make the hydrant connection.	15 a. To steamer outlet or outlet wi	th	
	adapter		
	b. Turning clockwise		
	c. hand tight		
16 Open the hydrant	16 a. Turning counterclockwise		
	b. Slowly until hose is full		
	c. Fully		
17 Tighten any leaking connections.	7 Using rubber mallet		

PERFORM A SINGLE SECTION DRAIN AND CARRY

Introduction

It frequently becomes necessary to drain excess water from a section of fire hose and to carry it a reasonable distance. Draining the hose is one task and preparing it to be carried is another. The following technique is a way by which both tasks can be performed at the same time for an accordion shoulder carry. The hose does not necessarily need to be in a straight line but sharp bends make it difficult to load.

Equipment and Personnel

One firefighter in protective clothing One length of 2 1/2-inch (65 mm) hose

Students Name

Instructors Name

Job Steps	Key Points	PASS	FAIL
1 Position the hose.	1 a. In a straight line		
	b. Flat		
	c. Couplings placed gently		
Position yourself.	2 a. At one end of hose		
	b. Facing opposite end		
3 Pick up the hose.	3 a. With either hand		
	b. Allowing water to flow forward		
4 Loop the hose over one shoulder.	4 a. Loop in back of body		
	b. Loop knee high		
	c. Coupling held at waist		
	d. Coupling facing down		
5 Walk forward	5 a. Holding hose in front of body		
	b. With both hands		
	c. Forming additional loops		
	d. In front and back of body		
	e. Layering over same shoulder		
	f. Loops knee high front and rear		
Continue walking forward.	6 a. To opposite end		
	b. Until section of hose has been drained		
	c. Until section is loaded on shoulder		
7 Adjust the load as necessary.	7 a. Hose flat on shoulder		
	b. Hose balanced on shoulder		
	c. Steadied with both hands in front		
8 Carry the hose.	8 20 feet (6 m)		
9 Lay the hose down.	9 a. On ground		
	b. Couplings placed gently		

ADVANCE A LINE INTO A STRUCTURE

Introduction

To effectively attack and extinguish structure fires, it is necessary for the firefighter to advance a hoseline from the apparatus into the structure and to the seat of the fire. Certain carries and advancing techniques have been developed that allow the firefighter to advance hose efficiently and rapidly.

Equipment and Personnel

Four firefighters (minimum) in protective clothing

Accordion-bedded hoseline

Students Name

Instructors Name

Job Steps	Key Points	PASS	FAIL
1 Unload the hose.			
2 Shoulder the hose.	2 a. Horseshoe shoulder		
3 Position yourselves for advancing.	b. All placing hose on same shoulder 3 a. Spaced about 12 feet (4 m) apart on same side of hose		
	b. Facing nozzle c. About 15 feet (5 m) to 20 feet (6 m) of hose between each firefighter		
4 Advance the hose.	4 a. To building entrance b. Not entering building		
5 Feel the door.	5 a. Firefighter on nozzle b. With back of ungloved hand b. Keeping low and to side of door opposite hinges		
6 Set the desired nozzle pattern.	6 a. 30- to 60-degree pattern for indirect attack b. 30-degree pattern for direct attack c. Bleeding all air out of hoseline		
7 Start the airflow in your SCBA unit.			
8 Enter the structure.	8 a. Staying low b. Not blocking doorway c. Maintaining spacing between firefighters		

ADVANCE A LINE DOWN AN INTERIOR STAIRWAY

Introduction

Advancing a hoseline in a stairway presents several problems. Hose is difficult to drag on flat, level ground and is exceedingly difficult to drag around obstructions found on a stairway. The shoulder carry and the underarm carry are adaptable to stairway advancement because hose is carried into position and fed out as needed. The minuteman carry is also excellent for use on stairways. The advancement of an uncharged hoseline down a flight of stairs is considerably easier than advancing a charged hoseline down stairways. However, because advancing a hoseline down a stairway often subjects firefighters to intense heat, in most cases the hoseline is charged when advancing down a stairway. Advancing an uncharged hoseline down stairways is recommended only when there is no fire, or a very minor fire, present.

Equipment and Personnel

Fire fighting team in full protective clothing 1 1/2-inch (38 mm) or larger hoseline

Structure with interior stairs

Students Name

Instructors Name

Job Steps	Key F	Points	PASS	FAIL
DOWN INTERIOR STAIRS (UNCHARGED HOSE				
Position yourselves for shouldering the	1 a.	Facing nozzle		
hoseline	b.	About 25 feet (8 m) to 20 feet (9 m) of		
		hose between each firefighter		
2 Place hose bundles on shoulders.	2 a.	Same shoulders		
	b.	Per appropriate shoulder carry		
3 Position stationary firefighters to help feed	3 a.	Along route and at top of stairs		
the hose and to keep hose on outside of	b.	At critical points (obstructions and		
staircase.		corners)		
	С.	Note: The last several firefighters can		
		assume these stationary positions		
		after their shoulder loads have payed		
		out.		
4 Advance the hoseline down a flight of	4 a.	Against outside wall		
stairs.	b.	Avoiding sharp bends and kinks		
	С.	Maintaining spacing between		
		firefighters		
	d.	Hose paying off shoulder of last		
		firefighter		
	e.	To fire floor		
5 (Last firefighter) Advance and assist	5 a.	After hose supply is depleted		
nozzle operator	b.	Removing kinks		
	c.	Pushing hose to outside wall of		
		stairway as necessary		
DOWN INTERIOR STAIRS (CHARGED HOSELIN	IE)			
1 Use the working drag to advance the line.				<u> </u>
2 Position stationary firefighters to help feed		Along route and at top of stairs		
the hose and to keep hose on outside of	b.	At critical points (obstructions and		
staircase.		corners)		

Job Steps	Key Points	PASS	FAIL
3 Advance down the stairs.	3 a. Against outside wall		
	b. Avoiding sharp bends and kinks		
	c. Maintaining spacing between		
	firefighters		
	d. Using working drag		
	e. To fire floor		
4 (Second firefighter) Advance and assist	4 a. After all hose is advanced		
nozzle operator.	b. Pushing hose to outside wall of		
	stairway		

HANDLE A MEDIUM-SIZED CHARGED HOSELINE (ONE FIREFIGHTER)

Introduction

When one firefighter is required to operate a medium sized hose and nozzle, some means must be provided for bracing and anchoring the hoseline.

Equipment and Personnel

One firefighter in protective clothing Charged 1 1/2-inch (38 mm) hoseline

Students Name

Instructors Name

Job Steps	Key Points	PASS	FAIL
1 Grasp the hose nozzle.	1 With one hand		
2 Grasp the hose.	2 a. With free hand		
	b. Just behind nozzle		
3 Step forward	3 a. In direction in which stream is to be		
	projected		
	b. Straightening the hoseline		
	c. Until at least 10 feet (3 m) of hose		
	behind the nozzle is straight		
4 Position hose for operation.	4 a. Nozzle pointing in desired direction		
	b. Hose cradled against inside of closest		
	leg		
	c. Hose braced against front of body and		
	hip		
	d. Foot of supporting leg on hose		
5 Operate the hose.	5 Opening nozzle slowly to reduce the		
	effect of nozzle reaction		

HANDLE A MEDIUM-SIZED CHARGED HOSELINE (TWO FIREFIGHTERS)

Introduction

A hoseline and nozzle must be kept under control at all times. The two-person method of handling a nozzle should be used whenever possible. It provided a greater degree of safety to the firefighters, is less fatiguing, and allows for mobility and speed of attack.

Equipment and Personnel

Two firefighters in protective clothing Charged 1 1/2-inch (38 mm) hoseline Rope hose tool or hose strap

Students Name

Instructors Name

Job Steps	Key F	oints	PASS	FAIL
1 Position yourselves	1 a.	On same side of hose		
	b.	Facing nozzle		
(Nozzle firefighter)				
2 Pick up the nozzle.		One hand grasping nozzle		
	b.	One hand, palm up, grasping hose		
		just behind nozzle		
	c.	Lifting with legs, not back		
3 Position the hose and nozzle	3 a.	Hose close to body, under arm		
	b.	Supporting hose with hose tool or		
		utility strap if available		
	c.	Keeping feet spread apart for balance		
		Nozzle hand on bale of nozzle		
4 (Backup firefighter) Pick up the hose.	4 a.	About 3 feet (1 m) behind firefighter		
		on nozzle		
	1	On same side of hose		
	c.	Grasping hose forward, palm down;		
		other hand palm up		
	d.	Resting hose against waist and		
		across hip		
	е.	Hose held at waist height		
	f.	Supporting hose with hose tool or		
		utility strap if available		
	g.	Hose straight behind nozzle firefighter		
		Feet spread apart for balance		
5 (Firefighter on nozzle) Operate the nozzle.	5	Opening nozzle slowly to reduce the		
		effect of nozzle reaction		

HANDLE A LARGE-SIZED CHARGED HOSELINE (TWO FIREFIGHTERS)

Introduction

Advancing large, charged hoselines to the fire must be done in such a manner that movement is fast, coordinated, and safe. Both firefighters must know the requirements of the job and must work together as a team. One firefighter controls the nozzle, and the second firefighter serves as an anchor. Close teamwork is a must.

Equipment and Personnel

Two firefighters in protective clothing

Charged 2 1/2-inch (65 mm) or larger hoseline

Rope hose tools or utility strap

Students Name

Instructors Name

Job Steps	Key Points	PASS	FAIL
KNEELING ANCHOR METHOD			
1 Position yourselves	1 a. On same side of hose		
	b. Facing nozzle		
(Nozzle firefighter)			
2 Pick up the nozzle.	2 a. One hand grasping nozzle		
	b. One hand, palm up, grasping hose		
	just behind nozzle		
	c. Lifting with legs, not back		
3 Position the hose and nozzle	3 a. Hose close to body, under arm		
	 b. Supporting hose with hose tool or 		
	utility strap if available		
	c. Keeping feet spread apart for balance		
	d. Nozzle hand on bale of nozzle		
4 (Backup firefighter) Kneel on the hose.	4 a. About 3 feet (1 m) from firefighter on		
	nozzle		
	b. With knee closest to hose		
	c. Both hands, palm down, on hoseline		
	near other knee		
5 (Firefighter on nozzle) Operate the nozzle	5 a. Opening nozzle slowly to reduce the		
	effect of nozzle reaction		
	b. Closing nozzle slowly to prevent water		
	hammer		
ROPE HOSE TOOL OR UTILITY STRAP ANCHO			
1 Position yourselves.	1 a. On same side of hose		
(-	b. Facing nozzle		
(Firefighter on nozzle)			
2 Position the rope hose tool or utility strap.	2 a. Looping around hose		
	b. Short distance from nozzle		
3 Pick up the hose nozzle.	3 a. One hand grasping nozzle		
	b. Other hand, palm up, grasping hose		
	just behind nozzle		
	c. Lifting with legs, not back		
4 Position the hoseline	4 a. Placing hose tool loop across back		
	and over outside shoulder		
	b. Resting hose against body		
	c. At hip level		

Job Steps	Key Points	PASS	FAIL
(Backup Firefighter			
5 Position yourself on the hoseline to serve	5 a. Same side of hose		
as anchor	b. Behind firefighter on nozzle		
	c. Feet apart for balance		
6 Position rope hose tool or utility strap.	6 a. Looping around hose		
	b. About 3 feet (1 m) from firefighter on		
	nozzle		
	c. Placing large loop across back and		
	over outside shoulder		
7 (Firefighter on nozzle) Operate the nozzle	7 a. Opening slowly to reduce the effect of		
	nozzle reaction		
	b. Both firefighters leaning slightly		
	forward for control		

USE COMBINATION ATTACK TO CONTROL AND/OR SIMULATE EXTINGUISHMENT OF A CLASS A FIRE WITHIN A STRUCTURE

Introduction

The combination attack method uses the steam-generating technique of ceiling level attack combined with a direct attack on materials burning near floor level.

Any fire attack must be coordinated to be successful. Coordination is not only crucial among the crews performing different functions, such as rescue, ventilation, and suppression, but it is also essential among the members of each team. Each team member should know his or her role in the attack and supression effort.

Equipment and Personnel

At least three firefighters per attack line, dressed in full protective clothing and SCBA

Class A fire, fueled, set up, and monitored according to NFPA 1403

One 1 1/2 -inch (38 mm) or larger charged attack line equipped with a fog nozzle

One 1 1/2-inch (38 mm) or larger charged backup line supplied for a second water source

Portable light

Axe

Prying tool

Students Name

Instructors Name

Job Steps	Key Points		PASS	FAIL
1 Start your SCBA airflow.	1	All members of team		
		CAUTION: A safety officer will check		
		your gear before you enter the		
		structure. Make sure that no skin or		
		hair is exposed!		
2 Position yourselves.	2 a.	On same side of attack line		
	b.	Nozzle firefighter in foremost position		
		At entrance but out of doorway		
	d.	Carrying equipment needed to force		
		entry or perform other tasks		
3 (Firefighter on nozzle) Set the nozzle flow.	3 a.	For a 30-degree fog pattern		
	b.	For 125 gallonage if applicable		
4 Open the nozzle.	4 a.	Fully		
	b.	Briefly		
	С.	Aiming stream to side		
	d.	Testing fog pattern		
	e.	Expelling air		
5 Extinguish burning fascia, boxed cornices,	5	As necessary before entering		
or other doorway overhangs.				
6 (Team) Advance the hose into the	6 a.	At signal from firefighter on nozzle		
structure.		All firefighters on same side of hose		
		Keeping low		
	d.	Leaving one firefighter at each 90-		
		degree turn to assist in advancing		
		hose		
	е.	Not bunching up behind firefighter on		
		nozzle		
	f.	Watching for hazardous conditions		
	g.	Approaching fire from unburned side		
	h.	Not opening nozzle until fire is		
		encountered		

Job Steps	Key F	Points	PASS	FAIL
7 (Firefighter on nozzle) Use the "T," "Z," or	7 a.	When you have reached your		
"O" pattern attack.	Ι.	objective		
	b.	Directing stream at ceiling level and		
		then dropping down to attack the		
		combustibles burning near the floor		
		Nozzle fully open		
		Until fire is darkened down		
8 (Team member) Open a designated	8	At instructor's command		
window to enable hydraulic ventilation.				
9 (Firefighter on nozzle) Force ventilate.	9 a.	Standing approximately 2 feet (0.62		
		m) from window		
		Aiming stream through open window		
	C.	Adjusting nozzle pattern as necessary		
		to fill 85 to 90 percent of window		
	l .	opening		
		Holding stream steady		
		Until fire area is cleared of smoke		
10 Extinguish hot spots.	10 a.	Direct attack at still flaming or glowing		
		areas		
		Short bursts		
		Until no hot spots rekindle		
11 (Team) Exit the fire building.	11 a.	Backing away from fire area with		
		shuffle step		
		Remaining low		
	C.	Taking up slack hose to prevent		
		tripping or falling		
	d.	Nozzles ready until all team members		
		are out of fire area.		
12 Stop SCBA airflow and doff SCBA masks.	12	When well clear of building		

DEMONSTRATE THE LOW-SHOULDER ROOF LADDER LIFT AND CARRY (FROM VERTICAL OR FLAT RACKING)

Introduction

The low-shoulder roof ladder carry is particularly well suited for making beam raises and for carrying a roof ladder when it is to be taken up another ladder.

Equipment

One firefighter

and Personnel Vertically and flat racked 12-foot to 20-foot (4 m to 6 m) roof ladders

Students Name

Instructors Name

Date			
Job Steps	Key Points	PASS	FAIL
VEDTICALLY DACKED/CIDE DEMOVAL			
1 Release the ladder locks.	T T		
2 Position yourself at the lifting point.	2 a. Balance point		
2 i osition yoursell at the litting point.	b. Near center of ladder		
3 Position yourself for lifting.	3 a. Facing ladder butt		
o i osition yoursen for inting.	b. Palm of the hand nearest ladder		
	under bottom beam.		
	c. Palm of other hand on top of upper		
	beam		
4 Position the ladder for carrying.	4 a. Lifted clear of brackets		
	b. Lower beam resting on shoulder		
	c. Butt lowered slightly		
5 Steady the ladder.	5 a. Holding upper beam		
o otoday the laddon	b. With one hand		
	c. Palm down		
6 Carry the ladder.	6 20 feet (6 m)		
7 Return the ladder to its rack.	7 a. Seated securely on brackets		
	b. Ladder locks engaged.		
VERTICALLY RACKED/REAR REMOVAL			
1 Release the ladder locks.			
2 Position yourself for unracking the ladder.	2 a. At rear of apparatus		
	b. Facing ladder to be removed		
3 Grasp the ladder.	3 a. By end rung		
	b. With both hands		
4 Pull the ladder from the rack.	4 Just until ladder remains extended		
	without support		
5 Position yourself for carrying	5 a. Facing ladder at midpoint		
	b. Grasping top and bottom beams		
	c. Lifting ladder to shoulder while		
	pivoting toward ladder butt		
6 Position ladder for carrying.	6 a. Lower beam resting on shoulder		
	b. Butt lowered slightly		
	c. Steadied with one hand palm down on		
	top beam and other on bottom beam		
	or convenient rung at point near		
	bottom beam		
	d. Hooks closed		
7 Carry the ladder.	7 20 feet (6 m)		
8 Return the ladder to its rack.	8 a. Reversing unracking procedure		
	b. Ladder locks engaged.		

lob Steps	Key F	Points	PASS	FAIL
LAT RACKED/SIDE REMOVAL				
1 Release the ladder locks.				
2 Position yourself for unracking.	2 a.	Alongside apparatus		
,		Facing midpoint of ladder		
3 Grasp the ladder.		By near beam		
·	b.	With both hands		
4 Pull the ladder from the rack.	4 a.	Straight outward		
	b.	Until near beam tilts downward		
5 Turn toward the ladder butt.	5	Pulling ladder onto shoulder		
6 Reposition ladder on shoulder.	6	Tilted up until vertical on shoulder		
7 Adjust your hand grip.	7 a.	Near hand palm up grasping lower		
, , , , ,		beam		
	b.	Top hand palm down grasping top		
		beam or high up on convenient rung		
		directly above head		
8 Position ladder for carrying	8 a.	Lower beam resting on shoulder		
		Butt lowered slightly		
		Steadied with both hands		
	d.	Hooks closed		
9 Carry the ladder	9	20 feet (6 m)		
10 Return the ladder to its rack.	10 a.	Reversing unracking procedure		
		Ladder locks engaged.		
AT RACKED/REAR REMOVAL	•			
1 Release the ladder locks.				
2 Position yourself for unracking the ladder.	2 a.	At rear of apparatus		
,		Facing ladder to be removed		
3 Grasp the ladder.		By end rung		
•		With both hands		
4 Pull the ladder from the rack.	4 a.	Just until ladder remains extended		
		without support		
5 Reposition yourself for carrying.	5 a.	Facing ladder at midpoint		
, , ,	b.	Grasping two convenient rungs		
		Lifting ladder to shoulder while		
		pivoting toward ladder butt		
6 Position ladder for carrying	6 a.	Lower beam resting on shoulder		
, ,		Butt lowered slightly		
		Steadied with both hands		
		Hooks closed		
7 Carry the ladder.	7	20 feet (6 m)		
8 Return the ladder to its rack.	8 a.	Reversing unracking procedure		
		Ladder locks engaged.		

DEMONSTRATE THE TWO-FIREFIGHTER FLAT RAISE FROM A LOW-SHOULDER CARRY

Introduction

Whether a ladder is raised parallel with or perpendicular to a building makes little difference. If raised parallel with the building, the ladder can always be pivoted after it is in the vertical position. Whenever two or more firefighters are involved in raising a ladder, the firefighter at the butt is responsible for placing the butt at a desired distance from the building and determining whether the ladder will be raised parallel with or perpendicular to the building.

When there are enough personnel for a three - or four-firefighter ladder raise, the flat raise is normally used. Four firefighters are desireable because they can more easily handle larger and heavier extension ladders.

The four-firefighter flat raise is similar to the two-firefighter flat raise except for the positioning of personnel.

Equipment and Personnel

30-foot (9.3 m) extension ladder

Two firefighters

Students Name

Instructors Name

bb Steps Key Points		PASS	FAIL
1 Lift and carry the ladder.	1 To work area		
2 Visually inspect the work area.	2 a. Terrain for solid, level footing		
	b. Overhead for electrical wires and		
	obstructions		
3 (Firefighter at butt) Lower the ladder butt to the ground.	3 Nonshoulder beam first		
4 Pivot the ladder.	4 (Firefighter at butt)		
4 i ivot tile lauder.	a. Until flat		
	b. Fly toward ground		
	(Firefighter at tip)		
	c. Simultaneously adjusting position		
	d. Placing one beam on shoulder		
5 (Firefighter at butt) Heel the ladder.	5 a. Standing on bottom rung		
o (i irenginer at batt) ricer the ladder.	b. Crouching down and grasping beams		
	or convenient rung with both hands		
	c. Leaning back		
6 (Firefighter at tip) Position yourself to	6 a. Swinging under ladder		
raise the ladder.	b. Grasping a convenient rung		
7 Bring the ladder upright.	7 a. Until ladder is vertical		
, and ideas aprigna	b. Until standing facing each other		
	through the ladder		
	(Firefighter at tip)		
	c. Advancing hand-over-hand		
	d. Toward the butt		
	(Firefighter at butt)		
	e. Advancing hand-over-hand		
	f. Toward tip		
8 (Outside firefighter) Steady the ladder	8 a. One foot against beam		
, , ,	b. Hands on beam		

Job Steps	Key Points		PASS	FAIL
9 (Inside firefighter) Extend the fly section	9 a.	To desired elevation		
	b.	Using hand-over-hand motion on		
		halyard		
	c.	Pulling halyard straight down		
	d.	Maintaining ladder balance		
10 Engage the ladder locks.	10	At desired elevation		
11 Lower the ladder to the building.	11 a.	Carefully and firmly		
		(Outside firefighter)		
	b.	One foot on bottom rung		
	c.	Beams grasped at shoulder height		
		(Inside firefighter)		
	d.	Beams grasped above head		
12 Tie off the halyard.	12 a.	Wrapping around two convenient		
		rungs		
	b.	Tying clove hitch		
	c.	Tying half hitch on top of clove hitch		
13 (Both firefighters) Pull the ladder butt out	13 a.	Pushing against upper rung		
from the building		Pulling lower rung		
	c.	Until at proper angle for climbing		
14 Secure the ladder for climbing.				
15 Lower the ladder.	15	Reversing raising procedure		

DEMONSTRATE THE ONE-FIREFIGHTER LADDER RAISE FROM A LOW-SHOULDER CARRY

Introduction

The major difference between a one-firefighter raise from the low-shoulder carry and a one-firefighter raise from the high-shoulder carry is the placement of the ladder butt. In these raises, the building is used to heel the ladder to prevent the butt from slipping while the ladder is brought to a vertical position.

Equipment and Personnel

24-foot (7 m) extension ladder

One firefighter

Students Name

Instructors Name

b Steps	Key Points	PASS	FAIL
1 Lift and carry the ladder.	1 To work area	1	
2 Visually inspect the work area.	2 a. Terrain for solid, level footing		
2 visually inspect the work area.	b. Overhead for electrical wires and		
	obstructions		
3 Lower the ladder butt to the ground	3 a. Butt spurs against building wall		
5 Lower the ladder butt to the ground	b. Fly in		
4 Position yourself to raise the ladder.	4 a. Grasping rung in front of your		
+ 1 osition yourself to raise the lauder.	shoulder with free hand		
	b. Removing other arm from betwee	n	
	the rungs	` `	
	c. Stepping beneath ladder and gras	pina	
	convenient rung with free hand	9	
5 Bring the ladder upright.	5 a. Advancing hand-over-hand		
o zimig and islander apriigini	b. Toward the butt		
	c. Until ladder is against building		
6 Move ladder butt out from the building.	6 a. While pushing against an upper ru	ına	
g .	to keep ladder against building	Ĭ	
	b. Grasping a lower rung		
	c. Carefully to desired angle		
7 Pull the ladder away from the building.	7 a. Grasping a covenient rung with bo	oth	
Ç	hands		
	b. Heeling ladder		
	c. Until in vertical position		
8 Balance ladder in a vertical position.	8 a. One foot at butt of one beam		
·	b. Ladder steadied with instep, knee	,	
	and leg		
9 Extend the fly section.	9 a. To desired elevation		
	b. Using hand-over-hand motion on		
	halyard		
	c. Pulling halyard straight down		
	d. Maintaining ladder balance		
10 Engage the ladder locks	10 At desired elevation		
11 Lower the ladder against the building.	11 a. Grasping beams		
	b. One foot against a butt spur or on		
	bottom rung		
	c. Gently		

Job Steps	Key Points		PASS	FAIL
12 Tie off the halyard.	12 a. Wrap	ping around two convenient		
	rungs	;		
	b. Tying	clove hitch		
	c. Tying	half hitch on top of clove hitch		
13 Roll the ladder laterally.	13 a. Bean	n-over-beam		
	b. Until	fly is out		
14 Pull the ladder butt out from the building.	14 a. Push	ing against upper rung		
	b. Pullir	g lower rung		
	c. Until	a proper angle for climbing		
15 Secure the ladder for climbing.				
16 Lower the ladder	16 Reve	rsing raising procedure		

SECURE A RAISED LADDER

Introduction

Ladders must be kept from slipping whenever firefighters climb them, especially if the ladder is at a lower-than-desirable angle or if there are strong winds or icy or unstable ground. Added stability is also necessary when operating hoselines from the ladder or when using the ladder for rescue.

Whenever possible, the ladder should be tied at both the top and bottom to a secure object. Tying prevents the ladder from slipping or falling away from the building and frees personnel who would otherwise heel the ladder.

Also, before an extension ladder is climbed, the excess halyard should be tied to the ladder to prevent the fly from slipping and to prevent persons from tripping over it.

Equipment and Personnel

Raised extension or straight ladder Rope hose tool or safety strap

One firefighter

Students Name

Instructors Name

l a a			
1 4 6			
	Annual true considerations		
	Around two convenient rungs		
	Pulled taut		
	· •		
D.	• • • • • • • • • • • • • • • • • • • •		
_			
+			
4	On top of clove filler		
1 4	Eggshield lawared		
	<u> </u>		
u.	• , ,		
<u> </u>	descended		
l 1 a	In front of ladder		
1	<u> </u>		
5.	<u>-</u>		
2 a	<u> </u>		
	· · · · · · · · · · · · · · · · · · ·		
	· · · · · · · · · · · · · · · · · · ·		
1	<u> </u>		
] 5.	• • •		
	2 a. b. 3 a. b. 4 a. b. c. d. b. 2 a. b. 3 a. b. 4 a. b. c. d. 5 b. c. d. 5 b. 6 b	2 a. Between thumb and forefinger b. Palm down 3 a. Palm turned up b. Halyard underneath and back over top of rung c. Pulled through loop 4 On top of clove hitch	2 a. Between thumb and forefinger b. Palm down 3 a. Palm turned up b. Halyard underneath and back over top of rung c. Pulled through loop 4 On top of clove hitch 1 Faceshield lowered 2 a. Standing under ladder b. Feet about shoulder width apart 3 a. Beams, not rungs b. About eye level 4 a. Firmly b. Toward building c. Not looking up d. Until firefighter(s) has ascended or descended 1 a. In front of ladder b. Toes of one foot against ladder heel, or one foot on bottom rung 2 a. Beams, not rungs b. About eye level 3 a. Firmly b. Toward building c. Staying alert for descending

Job Steps	Key Points	PASS	FAIL
TYING IN			
Tie the rope hose tool or safety strap to an appropriate ladder rung.	1 With clove hitch		
2 Secure the rope hose tool or safety strap.	2 a. Hooking, or tying securely with clove hitch		
	b. To any available secure object		

DEMONSTRATE THE TWO-FIREFIGHTER LOW-SHOULDER LADDER LIFT AND CARRY (FROM VERTICAL RACKING)

Introduction Lifting is easiest when ladders are vertically racked a little above shoulder height, and the firefighter

does not need to exert as much energy or caution against back strain as when lifting from the ground

or a lower racking.

Equipment

Two Firefighters

and Personnel Vertically racked 24-foot (7 m) extension ladder

Students Name

Instructors Name

Date

Steps	Key Points	PASS	FAIL
FREMOVAL			
E REMOVAL 1 Release the ladder locks.	T		
Position yourselves at lifting points	2 a. Facing ladder		
2 Fosition yourselves at litting points	b. One firefighter two or three rungs from		
	tip		
	c. Other firefighter two or three rungs		
	from butt		
	d. Both hands on convenient rungs.		
3 Lift the ladder from its brackets.	3 a. Up and out		
o Lift the ladder from its brackets.	b. With both hands		
4 Position yourselves for carrying	4 a. As soon as ladder clears rack		
4 1 osition yourselves for carrying	b. Continuing to grasp with hand nearest		
	butt		
	c. Placing other arm between two		
	convenient rungs		
	d. Pivoting simultaneously toward butt		
5 Position ladder for carrying.	5 a. Upper beam on shoulders		
o i comon made i for carrying.	b. Firefighter at butt covering upper butt		
	spur with outside hand		
6 Carry the ladder.	6 a. 20 feet (6 m)		
	b. Firefighter at butt clearing the way		
	Note: The forward firefighter is		
	responsible for using one hand to		
	move people out of the way to prevent		
	them from being struck by the butt		
	spur.		
7 Return the ladder to its rack.	7 a. Reversing unracking procedure		
	b. Seating ladder securely on brackets		
	c. Engaging ladder locks		
R REMOVAL			
1 Release the ladder locks.			
2 Position yourselves to unrack the ladder	2 a. At rear of apparatus		
	b. First firefighter opposite end of ladder		
	c. Second firefighter to one side of		
	ladder adjacent to apparatus		
3 Pull the ladder from its rack.	3 a. First firefighter grasping end rung		
	b. Second firefighter assisting		
	c. Straight back		
	b. Until second firefighter signals to stop		
	(when ladder is just ready to clear		
7 5 Two Eirofish	rack) Iter Low-Shoulder Ladder Lift and Carry		

Version 1.0 June 2006

Job Steps	Key Points	PASS	FAIL
4 (First firefighter) Shift your position	4 a. Adjacent to butt on same side as second firefighter b. Between last two rungs c. Maintaining ladder support		
5 Position yourselves to carry the ladder	5 a. Facing ladder butt b. Simultaneously placing arm closest to ladder between last two rungs at tip and butt		
6 Position ladder for carrying.	6 a. Pulled off rack b. Upper beam on shoulders c. Firefighter at butt covering upper butt spur with outside hand		
7 Carry the ladder.	7 a. 20 feet (6 m) b. Firefighter at butt clearing the way Note: The forward firefighter is responsible for using one hand to move people out of the way to prevent them from being struck by the butt spur		
8 Return the ladder to its rack.	8 a. Reversing unracking procedure b. Engaging ladder locks		

PROPERLY BREAK ORDINARY PLATE GLASS

Introduction

Because of its keen cutting edges, the ordinary plate glass in doors and windows must be broken according to an established procedure to assure firefighter safety. Impact on plate glass produces many long, pointed shards with sharp edges. Proper breaking procedures permit the broken shards of glass to fall downward, away from the firefighter's hands and to the side of where the firefighter stands.

CAUTION: Never break glass with your hands, gloved or ungloved. Also, take special care when breaking ordinary plate glass above the ground floor to prevent a "flying guillotine" hazard to citizens and firefighters below.

Equipment and Personnel

One firefighter in full protective clothing Plate glass door or window panel

Axe or other appropriate forcible entry tool

Students Name

Instructors Name

Job Steps	Key Points	PASS	FAIL
1 Adjust your protective gear.	1 a. Lowered faceshield		
	b. Gloves donned		
2 Position yourself	2 Windward side of glass		
3 Strike the glass	3 a. Top of pane		
	b. With forcible entry tool		
	c. Hands well above point of impact		
4 Remove the remaining glass from the	4 a. Forcible entry tool run around frame		
frame.	b. All shards removed from frame		

USE AN ELECTRIC OR GASOLINE-POWERED CIRCULAR SAW

Introduction

The following job steps provide general procedures for operating an electric or gasoline-powered circular saw. Be thoroughly familiar with the tool, its operating principles, methods, and limitations. ALWAYS read and follow the manufacturer's directions and cautions before powering or operating a tool.

CAUTION: Before powering or operating the following tool, you MUST be dressed in full protective clothing and wearing safety goggles under your lowered faceshield.

Equipment and Personnel

One firefighter in full protective clothing and helmet with faceshield

Safety goggles

Charged booster hose

Electric or gasoline-powered circular saw

Electric power source/outlet

Wrecked automobile(s) or other object(s) appropriate for skill demonstration

Students Name

Instructors Name

Job Steps	Key Points	PASS	FAIL
1 Check the area in which the work is to be done.	1 a. No ignition hazards		
CAUTION: Contact between the blade and metal may produce sparks that will ignite flammable vapors.	b. No flammable vapors		
2 Check the saw blade	2 a. Correct for job		
	b. Sharp		
	c. Undamaged in any way		
3 Check the oil level	3 a. Per manufacturer's instructions		
	b. Proper weight oil added if neces	ssary	
4 Check saw's safety features.	4 Blade and hand guards in place)	
5 Cool the saw blade when using on metals	5 a. Before cutting		
	 b. With a fine water mist from boo 	ster	
	line		
6 Adjust your protective clothing.	6 a. Safety goggles on		
	b. Faceshield lowered		
	c. Gloves on		
7 Provide power to the saw.	 7 a. Grounded power source (electr powered) 	ically	
	b. Proper octane gasoline (gasolir powered)	ne	
8 Start saw blade rotation	8 a. Blade not contacting work		
	b. (Electric) Switch in "on" position	1	
	c. (Gasoline) Compression button		
	depressed (if applicable) and co	ord	
	pulled per manufacturer's instru		
	and cautions.		

Job Steps	Key Points	PASS	FAIL
9 Make the cut(s)	9 a. Blade perpendicular to work		
CAUTION: Stay alert and deep hands on saw handles and away from material being cut. Power saws can easily sever	b. Power cord behind operator and away from blade (electrically powered)		
limbs and fingers.	c. Not forcing blade through material (blade doing the work)		
	d. Cooling blade often with fine water mist (if cutting metal)		
10 Stop the saw blade	10 a. When cut has been made		
•	b. Releasing trigger		
11 (Electric) Disconnect the saw from its power source.	11 Pulling on plug, not cord		
12 (Gasoline powered) Shut off the saw engine	12 Pushing the "kill" switch		
13 Return the tool to proper storage	13 Per manufacturer's instructions and department protocol		

DEMONSTRATE HYDRAULIC VENTILATION

Introduction Hydraulic ventilation requires using a 60-degree fog pattern covering 85 to 90 percent of an opening.

The fog stream is directed through a door or window to draw heat and smoke from the structure.

Equipment Fire fighting team in full protective clothing and SCBA Charged hoseline with fog nozzle

Charged hoseline with fog nozzle Smoke-filled training structure

ŭ

Students Name

Instructors Name

Job Steps	Key Points	PASS	FAIL
1 Exhaust air from hose.	Opening and closing the bale	e briefly	
2 Set the fog nozzle pattern.	2 60 degrees		
3 Start your SCBA airflow.	3 a. Facepiece sealed		
	b. No hair or skin showing		
	c. Mainline valve fully opened		
4 Enter the structure.	4 a. As a hose team		
	b. Keeping low		
	c. Mainline valve fully opened		
5 Start water flow.	5 a. Nozzle extended through ext	it opening	
	b. Nozzle bale pulled toward yo	ou	
6 Adjust the fog pattern.	6 a. Retracting nozzle		
	b. Until maximum air movemer	nt is	
	achieved		
	NOTE: Maximum air moven	nent	
	usually occurs about 2 feet (0.6m)	
	inside the ventilation opening		
7 Direct the fog stream.	7 a. Through opening and out of	structure	
-	b. Leaving room for air movem	ent	
	between fog pattern and side	es of	
	opening		
	c. Minimizing inside water flow		
	d. Not hitting personnel with str		
8 Stop the water flow.	8 a. After smoke has been cleare		
•	building		
	b. Nozzle bale pushed forward		
9 Exit the structure.	9 a. As hose team		
	b. Keeping low		
	NOTE: Rotate hose position	ns until	
	each team member has ope		
	hose nozzle to perform hydra		
	ventilation.		

USE AN ELECTRIC RECIPROCATING SAW

Introduction

The following job steps provide general procedures for operating an electric reciprocating saw. Be thoroughly familiar with the tool, its operating principles, methods, and limitations. *ALWAYS read and follow the manufacturer's directions and cautions before powering or operating a tool.*

CAUTION: Before powering or operating the following tool, you MUST be dressed in full protective clothing and wearing safety goggles under your lowered faceshield.

Equipment and Personnel

One firefighter in full protective clothing and helmet with faceshield

Safety goggles

Charged booster hose Electric reciprocating saw Electric power source/outlet

Wrecked automobile(s) or other object(s) appropriate for skill demonstration

Students Name

Instructors Name

Job Steps	Key P	oints	PASS	FAIL
1 Check the area in which the work is to be done.	1 a.	No ignition hazards		
CAUTION: Contact between the blade and metal may produce sparks that will	b.	No flammable vapors		
ignite flammable vapors.	↓			
2 Check the saw blade		Correct for job		
		Sharp		
		Undamaged in any way		
3 Check the saw's safety features.		Foot plate in place		
		Power cord in good condition		
4 Adjust your protective clothing.		Safety goggles on		
	1	Faceshield lowered		
		Gloves on		
5 Connect the saw to its power source.	5	Grounded		
6 Pick up and position the saw.		One hand on handle grip		
	1	Other hand under saw barrel		
	c.	Power cord behind you and away from		
		blade		
7 Depress the handle-grip starter button to start the saw blade	7	Blade not contacting work		
CAUTION: Stay alert and keep hands on				
saw handles and away from material				
being cut. Power saws can easily sever				
limbs and fingers.				
8 Make the cut(s)	8 a.	Blade perpendicular to work		
, ,	b.	Not forcing blade through material		
		(blade doing the work)		
9 Release the handle-grip starter button to	9	When cut has been made		
shut off the saw blade				
10 Remove the saw blade from the work.	10	Without bending blade		
11 Disconnect the saw from its power	11	Pulling on plug, not cord		
source.				
12 Return the tool to proper storage	12	Per manufacturer's instructions and		
		department protocol		

USE AN ELECTRIC OR GASOLINE-POWERED CHAIN SAW

Introduction

The following job steps provide general procedures for operating an electric or gasoline-powered CHAIN saw. Be thoroughly familiar with the tool, its operating principles, methods, and limitations. ALWAYS read and follow the manufacturer's directions and cautions before powering or operating a tool.

CAUTION: Before powering or operating the following tool, you MUST be dressed in full protective clothing and wearing safety goggles under your lowered faceshield.

Equipment and Personnel

One firefighter in full protective clothing and helmet with faceshield

Safety goggles

Charged booster hose

Electric or gasoline-powered chain saw

Electric power source/outlet

Wrecked automobile(s) or other object(s) appropriate for skill demonstration

Students Name

Instructors Name

Job Steps	Key Points	PAS	S FAIL	
1 Check the area in which the work is to be done.	1 a. No ignition	hazards		
CAUTION: Contact between the blade	b. No flamma	ble vapors		
and metal may produce sparks that will				
ignite flammable vapors.				
2 Check the chain teeth	2 a. Correct for	job		
	b. Sharp			
	c. Undamage	d in any way		
3 Check the chain.	3 a. Well oiled			
	b. Tight			
	c. Undamage			
4 Check the oil level.	4 a. Per manufa	acturer's instructions		
	b. Proper wei	ght oil added if necessary		
5 Check saw's safety features	5 a. Chain and	hand guards in place		
	b. Chain brak	e functional (if applicable)		
6 Adjust your protective clothing.	6 a. Safety gog	gles on		
	b. Faceshield	lowered		
	c. Gloves on			
7 Provide power to the saw.	7 a. Grounded	power source (electrically		
	powered)			
	b. Proper octa	ane gasoline (gasoline		
	powered)			
8 Start the chain rotation.	8 a. Chain not c	contacting work		
	b. (Electric) T	rigger in "on" position		
	c. (Gasoline)	Compression button		
		(if applicable) and cord		
		manufacturer's instructions		
	and caution			

Job Steps	Key F	Points	PASS	FAIL
9 Make the cut(s)	9 a.	Chain at effective angle to work		
CAUTION: Stay alert and deep hands on	b.	Power cord behind operator and away		
saw handles and away from material		from blade		
being cut. Power saws can easily sever	c.	Not forcing blade through material		
limbs and fingers.		(blade doing the work)		
10 Oil chain.	10 a.	Often		
	b.	Per manufacturer's directions		
11 Remove the chain from the work.	11	When cut has been made		
12 Stop the chain rotation.	12	Trigger released		
13 Set the saw down.	13 a.	When chain has stopped completely		
	b.	Where it will not be a tripping hazard		
14 (Electric) Disconnect the saw from its	14	Pulling on plug, not cord		
power source.				
15 (Gasoline powered) Shut off the saw	15	Pushing the "kill" switch		
engine				
13 Return the tool to proper storage	13	Per manufacturer's instructions and		
		department protocol		

FORCE AN OUT-SWINGING DOOR

Introduction

The least damaging method for opening a door that opens away from you (out-swing door) is to remove the door's hinges and then the door. If this cannot be accomplished, however, the door must be forced.

CAUTION: Before performing the following job, you MUST be dresSed in full protective clothing with faceshield lowered.

Equipment

Two firefighters in full protective clothing: one needed for ordinary, inexpensive door; both needed

for more sturdy door

and Personnel

Selection of forcible entry tool(s) Out-swinging door(s) to be forced

Students Name

Instructors Name

Job Steps	Key Points	PASS	FAIL
1 Size up the situation	1 a. Door tried		
	b. Door construction examined		
	c. Lock examined		
2 Adjust your protective gear.	2 a. Faceshield lowered		
	b. Gloves donned		
3 Insert blade of tool(s) in door.	3 (Ordinary door)		
	a. Between door and jamb		
	b. Near lock		
	(Sturdy door)		
	a. Between door and jamb		
	b. One tool just above lock		
	c. Second tool just below lock		
4 Force the tool blade in.	4 a. Against rabbet or stop		
	b. Worked, pushed, or driven in with		
	appropriate tool		
5 Move the door and jamb apart.	5 (Ordinary door)		
	a. Applying leverage to tool bar		
	b. Prying away from door		
	(Sturdy door)		
	a. Alternately prying with one tool		
	b. Catching bite with second tool		
6 Open the door.	6 a. When lock has cleared keeper		
-	b. Pulling open or prying open with		
	another tool		

FORCE AN IN-SWINGING DOOR (STOPPED JAMB)

Introduction

Doors having stopped jambs and that open away from the firefighter are more difficult to force than those that open toward the firefighter. As in forcing doors that open toward you, several forcible entry tools may be used for this operation. Regardless of which tool is selected, however, the procedure is the same.

CAUTION: Before performing the following job, you MUST be dressed in full protective clothing with faceshield lowered.

Equipment and Personnel

One firefighter in full protective clothing

Selection of forcible entry tools

In-swinging door(s) with stopped jamb

Students Name

Instructors Name

Job Steps	Key Points	PASS	FAIL
1 Size up the situation	1 a. Door tried		
	b. Door construction examined		
	c. Door lock examined		
2 Adjust your protective gear.	2 a. Faceshield lowered		
	b. Gloves donned		
3 Loosen or remove the door stop.	3 a. Paint or varnish seal broken		
	b. Loosened at lock or removed		
4 Pry the door away from the jamb.	4 a. Blade between door and jamb		
	b. Initial pry when blade is halfway		
	inserted		
	c. When full bite behind door		
	b. Until bolt passes keeper		
5 Open the door.	5 Pushed inward		

FORCE AN IN-SWINGING DOOR (RABBETED JAMB)

Introduction

Doors having rabbeted jambs and that open away from the firefighter can be more easily forced with two tools and two firefighters. Even with two tools, however, forcing this type of door construction can be difficult. Several forcible entry tools may be used for this operation. Regardless of which tool is selected, the procedure is the same.

CAUTION: Before performing the following job, you MUST be dressed in full protective clothing with faceshield lowered.

Equipment and Personnel

Two firefighters in full protective gear Selection of forcible entry tools

In-swinging door(s) with rabbeted jamb

Students Name

Instructors Name

Job Steps	Key Points	PASS	FAIL
1 Size up the situation	1 a. Door tried		
	 b. Door construction examined 		
	c. Door lock examined		
2 Adjust your protective gear.	2 a. Faceshield lowered		
	b. Gloves donned		
3 Spread the jamb	3 (1st firefighter)		
	 a. Tool blade flat against door 		
	 b. Blade between rabet and door 		
	c. Short pries		
	(2nd firefighter)		
	 a. Blade between door and jamb 		
	 b. Blade hammered well into opening 		
	 c. Appropriate driving tool 		
4 (Both firefighters) Pry the jamb away from	4 a. When a full bite behind door		
the door			
	b. Until bolt passes keeper		
5 Open the door.	5 Pushed inward		

FORCE A CHECKRAIL (DOUBLE-HUNG) WINDOW

Introduction

Checkrail (double-hung) windows may be either metal or wood. They consist of an upper sash and a lower sash that meet in the center of the window. The sashes may be locked together on the inside by a latch or bolt. When screens are used with these windows, they are external and often aluminum framed.

CAUTION: Never break glass with your hands, gloved or ungloved. Also, take special precautions when breaking windows above the ground floor to prevent a "flying guillotine" hazard to citizens and firefighters below.

Equipment and Personnel

One firefighter in full protective clothing

Forcible entry prying tool

Pick-head axe

Piece of wood or tool for propping the window open

Checkrail window(s) to be forced

Students Name

Instructors Name

Job Steps	Key Points	PASS	FAIL
NOOD FRAME			
1 Size up the situation	1 a. Window tried b. Window construction examined c. Window locking method determ		
2 Adjust your protective gear.	2 a. Faceshield lowered b. Gloves donned		
3 Remove the window screen if one is used	3 Frame pried or screening cut or	ut	
4 Insert the tool blade	4 Between windowsill and center bottom sash	of	
5 Force the window	5 a. Prying up against sash b. Until lock screws are pulled out sashes separate.	and	
6 Raise the window sash.	6 a. Bottom sash b. Propped open to allow entry		
IETAL FRAME			
1 Size up the situation	1 a. Window tried b. Window construction examined c. Window locking method determ		
2 Adjust your protective gear.	2 a. Faceshield lowered b. Gloves donned		
3 Remove the window screen if one is used	3 Frame pried or screening cut of	ut	
4 Position yourself to break the window glass	4 Windward side of glass		
5 Strike the glass	5 a. Top of pane b. With forcible entry tool c. Hands well above point of impa	act	
6 Remove the remaining glass from the frame	6 a. Tool run around frame b. All shards removed from frame		
7 Unlock the sashes.	7 a. Reaching through window oper b. Unlatching or unbolting	ning	
8 Raise the window sash.	8 a. Bottom sash b. Propped open if necessary		

Job Steps	Key Points	PASS	FAIL
	NOTE: Generally, double hung windows are counter-weighted to keep them open. They will need propping		
	only if the counter-weights are broken		

VENTILATE A PITCHED ROOF

Introduction The procedures for opening pitched roofs are similar to those for opening flat roofs, but additional precautions must be taken to prevent slipping.

Equipment and Personnel

Teams of two firefighters in full protective gear and SCBA, relief rotated in

Pitched training roof Extension ladder Roof ladder Pike pole

Pick-head axe or power saw

Students Name

Instructors Name

ob Steps	Key Points	PASS	FAIL
4 Determine the leasting for the amorine	I d a Cinina un interesituativa		
1 Determine the location for the opening	1 a. Sizing up intensity of fire		
	b. Sizing up extent of fire		
	c. Identifying direction of wind		
	d. Sizing up existing exposure hazards		
	e. Identifying any obstructions		
2 Place and secure an extension ladder to access the roof	2 a. Team carry		
NOTE: The ladder may be raised and	b. Team raise		
secured by the instructor. If not, it should	c. At least three ladder rungs extending		
be carried, raised, and secured.	d. Tied in		
3 Ensure that the power saw is operable.	3 a. Power source available (if electrically powered)		
	b. Turned on briefly before ascending ladder		
4 Carry needed tools up the ladder.	4 a. Proper climbing techinque		
·	b. Roof ladder hooks open and facing		
	out.		
	c. Axe blade away from body, pick-head		
	in hand		
	d. Pike pole pike forward, slid up rail		
	e. Power saw off		
5 Assess the roof for warning signs of	5 a. Identifying melting asphalt		
unsafe condition, and orally report to your	b. Identifying "spongy" roof (roof that has		
instructor.	spring and rebound when walked		
	upon)		
	c. Identifying smoke coming from roof		
	d. Identifying fire coming from roof		
	e. Identifying downed or low electrical		
	wires or connections, antennas, or		
	lightning devices; broken skylights		
6 Place the roof ladder.	6 a. Hooks over roof peak		
·	b. To one side of the selected location		
	c. Upwind		
	d. Tested secure		

o Steps	Key Points	PASS	FAIL
7 Sound to locate the roof supports	7 a. With axe		
	b. Several locations		
	c. Axe not raised above shoulder level		
8 Mark off the location for the opening	8 a. Scratching roof surface with axe pick		
	b. Square or rectangular outline		
	c. 4 x 4 feet (1.2 m by 1.2 m)		
9 Remove the outer roofing material.	9 a. Completely		
	b. Cutting with axe blade		
	c. Pulling material out of way with axe		
	pick		
10 Cut each side of the decking with an a	xe 10 a. Short strokes (axe)		
or power saw.	b. Not raised above shoulder level (axe)		
	c. Guards in place (power saw)		
	d. Diagonally		
	e. Alongside rafter or joist		
	f. Full outlined distance		
	g. Joists uncut		
11 Practice relieving one another when	11 a. Relief firefighter approaching		
cutting	ventilation firefighter from rear		
-	b. Relief firefighter placing hand on		
	ventilation firefighter's shoulder		
	c. Ventilation firefighter freezing in		
	position until relief verbally indicates		
	what to do		
12 Pry up and remove the sheathing boar	ds. 12 a. Using axe pick		
•	b. Boards clear of work area		
13 Open the ceiling below.	13 a. After decking and sheathing fully cut		
-	b. Positioning self upwind		
	c. With pike pole or other suitable tool		
	d. Using blunt end of tool		

DEMONSTRATE MECHANICAL POSITIVE-PRESSURE VENTILATION

Introduction

Positive-pressure ventilation requires placing a blower outside a structure and blowing air into a structure in which an opening has been made to allow smoke and gases to escape. This method is faster and better than negative-pressure ventilation, especially if the operation is coordinated so that ventilated rooms can be shut to increase the blower's effects.

Equipment and Personnel

Two or three firefighters in full protective clothing and SCBA

One or two smoke blowers

Straight ladders or other means of support for ejectors

Forcible entry tools as applicable Smoke-filled training structure

Charged hoseline

Students Name

Instructors Name

Job Steps	Key Points	PASS	FAIL
1 Assess conditions and the structure to	1 a. Sizing up proximity and size o	f natural	
determine where to place blower(s)	openings		
	b. Identifying direction of wind		
	c. Sizing up intensity of wind		
	d. Sizing up position and intensit	y of fire	
	e. Sizing up existing exposures		
2 Regulate the exhaust opening.	2 a. Making 75 to 150 percent as I	arge as	
	entry opening		
	b. Closing all other exterior exits		
3 Place the blower	3 a. Carrying by handles		
	b. Positioning on uninvolved (pre	eferably	
	windward) side of building)		
	c. Positioning several feet outsic	le point	
	of entry		
	d. Ensuring that cone of air com	pletely	
	covers entry opening		
	b. Positioning so that fan blows i	n	
4 Observe safety precautions.	4 a. Allowing no one near blades of	or in	
	discharge area.		
	b. Using explosion-proof blower	motor	
	and power cable connections		
	c. Having a charged hoseline at	point of	
	entry		
5 Start the blower	5 a. Pulling on starter rope		
	b. Standing to one side of discha	arge	
	area		
6 Establish the desired draft path between	6 a. Removing all obstacles to airf	low	
the entry and exit openings.	b. Ensuring that air intake side o	f blower	
	is unblocked and free of debri	s	
	c. Creating an airflow path that is	s as	
	straight as possible		
	d. Closing or opening interior do	ors	
	systematically as appropriate		
	e. Keeping exit opening in propo	rtion to	
	entry opening		

Job Steps	Key Points	PASS	FAIL
7 Turn off the blower and disconnect it from	7 a. After smoke has been cleared from		
the power source.	building		
	b. Turning blower switch to "off" position		
	c. Pulling on plug, not cord		

DEMONSTRATE MECHANICAL NEGATIVE-PRESSURE VENTILATION

Introduction

Negative-pressure ventilation requires the placement of a fan or smoke ejector in a window or door blowing out of the structure and drawing smoke through the blower. Fresh air is drawn into the structure through a second opening, replacing the smoke and gases.

Equipment and Personnel

Two or three firefighters in full protective clothing and SCBA

One or two smoke blowers

Straight ladders or other means of support for ejectors

Forcible entry tools as applicable Smoke-filled training structure

Charged hoseline

Students Name

Instructors Name

Job Steps	Key Points	PASS	FAIL
1 Assess conditions and the structure to determine where to place ejector(s)	a. Sizing up proximity and size of natura openings b. Identifying direction of wind		
	c. Sizing up intensity of wind		
	d. Sizing up position and intensity of firee. Sizing up existing exposures		
2 Hang or place the exhausting smoke	2 a. Carrying by handle		
ejector.	b. Placing in open window or door		
	c. Placing to exhaust in same direction as wind		
	d. Placing as high as possible		
	e. Supporting appropriately		
3 Block off the opening around the	3 a. With salvage covers or other material		
exhausting ejector fan.	b. Completely		
4 Open a second door or window for air	4 a. In line with exhausting ejector		
	b. Farthest from exhausting ejector		
5 Place intake ejector if necessary.	5 a. Only if natural wind is too light to be effective		
	b. Positioning in second door or window opening, or several feet (meters) from opening		
	c. Positioning so that fan blows into structure		
6 Observe safety precautions.	6 a. Allowing no one near blades or in intake or discharge areas		
	b. Using explosion-proof blower motor and power cable connections		
	c. Having charged hoseline at intake opening		

Job Steps	Key Points	PASS	FAIL
7 Establish draft path.	7 a. Allowing no recirculation at exhausting ejector b. Creating an airflow path that is as straight as possible c. Removing all obstacles to airflow d. Opening or closing appropriate inside doors e. Keeping discharge and intake areas unobstructed		
8 Connect the ejector(s) to the power source, and turn on.	8 a. First ensuring that no personnel are near the intake and discharge areas b. Turning ejector switch(es) to "on" position		
9 Turn off ejector(s) and disconnect from power source.	9 a. After smoke and gases are cleared from building b. Turning ejector switch(es) to "off" position c. Pulling on plug, not cord		

SAFELY MOUNT, USE APPARATUS SAFETY EQUIPMENT, AND DISMOUNT APPARATUS

Introduction The most common dangerous experience faced by all firefighters is riding the apparatus to and from

emergency calls. To ensure personal safety, it is essential that all firefighters know and practice safety

on all fire service apparatus.

Equipment and Personnel

Response team

Protective clothing and SCBA

Ear and eye protection

Apparatus

Students Name

Instructors Name

Job Steps	Key Points	PASS	FAIL
WHEN DISORIENTED			
1 Don protective clothing.	Bunker coat and pants, boo helmet	its, hood,	
2 Mount the apparatus.	2 Using handrails		
3 Don SCBA (if seat-mounted).			
4 Use apparatus safety equipment.	 4 a. Connecting seat belt b. Donning ear protection (if no warrants or if in jump seat) c. Lowering faceshield (if in jump d. Locking safety gates or bars jump seat) 	mp seat)	
5 (Officer in charge) Signal driver.	5 When all firefighters are full and in secure positions	y clothed	
6 (Driver) Drive the apparatus.	6 Distance and destination sp instructor	ecified by	
7 Release apparatus safety equipment	7 When apparatus has come stop	to a full	
8 Dismount the apparatus	8 Using one of the following m Ordinary dismount: using	ı handrail	
	Energized dismount: dem method of jumping clear v apparatus may be in conta energized electrical wires	when act with	
9 Don SCBA (if not seat-mounted)	9 Per department SOPs		